

OPERATOR'S MANUAL

MODEL #100889 2500W PORTABLE INVERTER GENERATOR



REGISTER YOUR PRODUCT ONLINE

at championpowerequipment.com













or visit championpowerequipment.com

SAVE THESE INSTRUCTIONS. This manual contains important safety precautions which should be read and understood before operating the product. Failure to do so could result in serious injury. This manual should remain with the product.

Specifications, descriptions and illustrations in this manual are as accurate as known at the time of publication, but are subject to change without notice.

This product meets the requirements of the PGMA (Portable Generator Manufacturers' Association) standard ANSI/PGMA G300-2015 (Safety and Performance of Portable Generators).

TABLE OF CONTENTS	
Introduction	3
Safety Definitions	3
Important Safety Instructions	
Fuel Safety Safety and Dataplate Labels	
Safety Symbols	
Operation Symbols	
Quickstart Label Symbols	
Controls and Features	
Generator Generator	
Control Panel	
FCC Statement	
Parts Included	
Assembly Unpacking	
Add Engine Oil	
Add Fuel	
Grounding	
Operation	16
Generator Location	
Surge Protection	
Starting the Engine	
Connecting Electrical Loads	
Do Not Overload Generator	18
Eco (Economy) Mode	18
12V DC Automotive Style Outlet	19
Parallel Operation	19
Stopping the Engine	
Moving the Generator	
Operation at High Altitude	20
Maintenance	20
Cleaning the Generator	21
Changing the Engine Oil	
Cleaning and Adjusting the Spark Plug	
Cleaning the Air Filter	
Cleaning the Spark Arrestor	
Adjusting the Governor	
Maintenance Schedule	

Storage	23
Short Term Storage (up to 30 days)	23
Mid Term Storage (30 days – 1 year)	23
Long Term Storage (more than 1 year)	24
Removing from Storage	24
Specifications	25
Generator Specifications	25
Engine Specifications	25
Oil Specifications	25
Fuel Specifications	25
Temperature Specifications	25
Parts Diagram	26
Parts List	27
Engine Parts Diagram	29
Engine Parts List	30
Wiring Diagram	32
Troubleshooting	33
Warranty*	34
Warranty Qualifications	34
Repair/Replacement Warranty	34
Do Not Return The Unit To The Place Of Purchase	34
Warranty Exclusions	34
Other Exclusions	34
Limits of Implied Warranty and Consequential Damage	34
Contact Information	34

INTRODUCTION

Congratulations on your purchase of a Champion Power Equipment (CPE) product. CPE designs, builds, and supports all of our products to strict specifications and guidelines. With proper product knowledge, safe use, and regular maintenance, this product should bring years of satisfying service.

Every effort has been made to ensure the accuracy and completeness of the information in this manual at the time of publication, and we reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

CPE highly values how our products are designed, manufactured, operated, and serviced as well as providing safety to the operator and those around the generator. Therefore, it is IMPORTANT to review this product manual and other product materials thoroughly and be fully aware and knowledgeable of the assembly, operation, dangers and maintenance of the product before use. Fully familiarize yourself, and make sure others who plan on operating the product fully familiarize themselves too, with the proper safety and operation procedures before each use. Please always exercise common sense and always err on the side of caution when operating the product to ensure no accident, property damage, or injury occurs. We want you to continue to use and be satisfied with your CPE product for years to come.

When contacting CPE about parts and/or service, you will need to supply the complete model and serial numbers of your product. Transcribe the information found on your product's nameplate label to the table below

CPE TECHNICAL SUPPORT TEAM 1-877-338-0999 MODEL NUMBER 100889 SERIAL NUMBER DATE OF PURCHASE PURCHASE LOCATION

SAFETY DEFINITIONS

The purpose of safety symbols is to attract your attention to possible dangers. The safety symbols, and their explanations, deserve your careful attention and understanding. The safety warnings do not by themselves eliminate any danger. The instructions or warnings they give are not substitutes for proper accident prevention measures.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE indicates information considered important, but not hazard-related (e.g., messages relating to property damage).

IMPORTANT SAFETY INSTRUCTIONS

A WARNING

Cancer and Reproductive Harm - www.P65Warnings.ca.gov

A DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poisonous gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

OPERATE GENERATOR <u>OUTDOORS</u> ONLY IN A WELL VENTILATED AREA AND POINT EXHAUST AWAY.

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle.

DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings.

A DANGER

Using a generator indoors **CAN KILL YOU IN MINUTES**. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.

NEVER use inside a home or garage, **EVEN IF** doors and windows are open.

ONLY use **OUTSIDE** and far away from windows, doors, and vents.



Install battery-operated carbon monoxide alarms or plug-in carbon monoxide alarms with battery back-up according to the manufacturer's instructions.

A WARNING

Although the generator contains a spark arrester, maintain a minimum distance of 5 ft. (1.5 m) from dry vegetation to prevent fires.

A DANGER

Operate equipment with guards in place.

Rotating parts can entangle hands, feet, hair, clothing and/or accessories. Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts.

Tie up long hair and remove jewelry.

DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

A DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed. Use only Champion electrical cords for proper application.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator.

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Connection to your home's electrical system requires a listed 30A transfer switch installed by a licensed electrician and approved by the local authority having jurisdiction. The connection must isolate the generator from the utility power and must comply with all applicable laws and electrical codes.

A WARNING

Do not use generator for medical and life support uses.

In case of emergency, call 911 immediately.

NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

A WARNING

Spark from removed spark plug wire can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug or any other metal object.

DO NOT check for spark with the plug removed.

Use only approved spark plug testers.

A WARNING

Running engines produce heat. Severe burns can occur on contact. Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases.

Allow equipment to cool before touching.

Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling.

Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

A WARNING

Rapid retraction of the recoil cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the recoil cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in and turned on.

A CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

A CAUTION

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off and disconnect before stopping the generator.

A CAUTION

Improper treatment or use of the generator can damage it, shorten its life or void the warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust, or dirt.

DO NOT allow any material to block the cooling slots.

If connected devices overheat, turn them off and disconnect them from the generator.

DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

Fuel Safety

A DANGER

GASOLINE AND GASOLINE VAPORS ARE HIGHLY FLAMMABLE AND EXPLOSIVE.

Fire or explosion can cause severe burns or death.

Gasoline and gasoline vapors:

- Gasoline is highly flammable and explosive.
- Gasoline can cause a fire or explosion if ignited.
- Gasoline is a liquid fuel but it's vapors can ignite.
- Gasoline is a skin irritant and needs to be cleaned up immediately if spilled on skin or clothes.
- Gasoline has a distinctive odor, this will help detect potential leaks quickly.
- Gasoline expands or contracts with ambient temperatures.
 Never fill the gasoline tank to full capacity, as gasoline needs room to expand when temperatures rise.
- In the case of any petroleum gasoline fire, flames should never be extinguished unless the fuel supply valve can be turned OFF. By not doing so, if a fire is extinguished and the supply of fuel is not turned OFF, an explosion hazard could be created.

When adding or removing gasoline:

DO NOT light or smoke cigarettes.

Always turn the generator off and let cool for a minimum of two minutes before removing the gasoline cap. Afterwards, loosen gasoline cap to relieve pressure from the gasoline tank.

Only fill or drain gasoline outdoors in a well-ventilated area.

DO NOT pump gasoline directly into the generator at the gas station. Always use an approved fuel container to transfer the gasoline to the generator.

DO NOT overfill the gasoline tank.

Always keep gasoline away from sparks, open flames, pilot lights, heat and other sources of ignition.

When starting the generator:

DO NOT attempt to start a damaged generator.

Always make certain that the gasoline cap, air filter, spark plug, fuel lines and exhaust system are properly secured, connected and in place.

Always allow spilled gasoline to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation.

DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel valve is in the OFF position and the gasoline tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

Do not store generator or gasoline near furnaces, water heaters, or any other appliances that produce heat or have automatic ignitions.


A WARNING


Never use a gasoline container, gasoline tank, or any other fuel item that is broken, cut, torn or damaged.

Safety and Dataplate Labels

These labels warn you of potential hazards that can cause serious injury. Read them carefully.

If a label comes off or becomes hard to read, contact Technical Support Team for possible replacement.





Safety Symbols

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.

SYMBOL	MEANING
	Read Operator's Manual. To reduce the risk of injury, user must read and understand operator's manual before using this product.
↓ 5ft/1.5m	Clearance. Keep all objects at least 5 feet (1.5m) from generator. Heat from the muffler and exhaust gas can ignite combustible objects.
	Ground. Consult with local electrician to determine grounding requirements before operation.
<u>A</u>	Electric Shock. Failure to use in dry conditions and to observe safe practices can result in electric shock. Improper connections to a building can allow current to backfeed into utility lines, creating an electrocution hazard. A transfer switch must be used when connecting to a building.
	Fire/Explosion. Fuel and its vapors are extremely flammable and explosive. Fire or explosion can cause severe burns or death. Keep generator at least 5 feet (1.5m) from all objects to prevent combustion.
	Hot Surface. To reduce the risk of injury or damage, avoid contact with any hot surface.
	Open Flame Alert. Fuel and its vapors are extremely flammable and explosive. Keep fuel away from smoking, open flames, sparks, pilot lights, heat, and other ignition sources.
	Wet Conditions Alert. Do not expose to rain or use in damp locations.

Operation Symbols

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.

SYMBOL	MEANING
8	ON
②	STOP or OFF
	Choke. Pull choke knob to "CHOKE" position.
ÐIŧI	Run. Push choke knob to "RUN" position.
12 V	12V Direct Current
3	Circuit Breaker Reset: Push

SYMBOL	MEANING
I+@+I	Parallel Connection(s)
•	Ground Terminal
	Overload Reset Switch
Ť	Low Oil
ECO	Economy Mode Switch

Quickstart Label Symbols

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.



Starting the Engine

A DANGER

Move generator outside and far away from windows, doors and intake ventilation covers.

- 1. Check oil level.
 - Recommended oil is 10W-30.
- 2. Check gasoline level.

When adding gasoline, use a minimum octane rating of 85 and an ethanol content of 10% or less by volume.

- 3. Turn the fuel cap vent lever to the "ON" position.
- 4. Turn the fuel dial clockwise to the full "ON" position.
- 5. Pull choke knob to "CHOKE" position.
- 6. Pull the recoil cord.
- 7. Push the choke knob to "RUN" position.
- 8. Plug in desired device.


Stopping the Engine


- 1. Turn off and unplug all connected electrical loads.
- 2. Turn the fuel dial to the "STOP" position.

CONTROLS AND FEATURES

Read this operator's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.


Generator





- 1. Carrying Handle Used to lift or carry the unit.
- 2. **Recoil Starter** Used to manually start the engine
- 3. Control Panel See Control Panel section.
- 4. Fuel Cap Remove to add fuel.
- 5. **Fuel Lever Vent** Turn this valve to the "ON" position to supply air to the tank.
- 6. Spark Plug Access Cover
- 7. Maintenance Cover
- 8. Muffler

Control Panel



- 1. **Parallel Outlets** Used for parallel operation (parallel kit sold separately).
- 2. **Ground Terminal** Consult an electrician for local grounding regulations.
- 3. **AC Output Indicator Button** Indicates when power is being delivered to receptacle.
 - 3a. Green Systems Normal.
 - 3b. Red Constant- Overload Warning.
 - 3c. Red Flash- Overload Fault. Push to reset.
- 4. **Oil Warning Indicator Light** When ON engine will shut down and not run. Check oil level.
- Economy Mode Button Enables/disables automatic idle control.
 - 5a. OFF Economy Mode is OFF.
 - 5b. Green Economy Mode is ON.
- 6. Fuel Dial Used to start and stop the generator.
- 7. **Choke** Used to start a cold engine.
- Circuit Breakers (Push Reset) Protects the generator against electrical overloads.

RECEPTACLES		
A	4	(2×) 120V AC, 20A (NEMA 5-20R) May be used to supply electrical power for operation of 120 Volt AC, 20 Amp, single phase, 60 Hz electrical loads.
В		12V DC, 8A (Automotive) May be used to supply electrical power for operation of 12 Volt DC, 8 Amp electrical loads.

FCC Statement

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1a. This device may not cause harmful interference.
 - This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult dealer or an experienced radio/TV technician for help.

Parts Included

Accessories

Engine Oil	16.9 fl. oz. (500 ml)
Oil Funnel	1
Dual Port USB Adapter (5v/2.4A)	1
Battery Charging Cables	



ASSEMBLY

Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our Technical Support Team at 1-877-338-0999. Please have your serial number and model number available.

Unpacking

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- 3. Using the carrying handles of the unit, carefully remove the generator from the box (two people lifting is recommended).

Add Engine Oil

A CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failing to follow these instructions will void your warranty.


NOTICE

The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.


NOTICE

The recommended oil type for typical use is **10W-30** automotive oil.


If running generator in extreme temperatures, refer to the following chart for recommended oil type.




- 1. Place the generator on a flat, level surface.
- 2. Loosen the cover screws and remove the maintenance cover.



- 3. Remove oil fill cap/dipstick to add oil.
- 4. Using a funnel, add up to 16.9 fl. oz. (500 ml) of oil (included) and replace oil fill cap/dipstick. DO NOT OVERFILL.



5. Check engine oil level daily and add as needed.



NOTICE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole.

When using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

NOTICE

Check oil level often during the break-in period. Refer to the Maintenance section for recommended service intervals.

A CAUTION

This engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

NOTICE

The first 5 hours of run time are the break-in period for the unit. During the break in period stay at or below 50% of the running watt rating and vary the load occasionally to allow stator windings to heat and cool. Adjusting the load will also cause engine speed to vary slightly and help seat piston rings. After the 5 hour break-in period, change the oil.


NOTICE

Synthetic oil may be used after the 5 hour initial break-in period. Using synthetic oil does not increase the recommended oil change interval. Full synthetic 5W-30 oil will aid in starting in cold ambient $< 41^{\circ}$ F (5° C) temperatures.

Add Fuel

DO NOT mix oil with gasoline.

- 1. Remove the gasoline cap.
- 2. Slowly add gasoline to the tank. DO NOT OVERFILL. Gasoline can expand after filling. A minimum of ¼ in. (6.4 mm) of space left in the tank is required for gasoline expansion, although more than ¼ in. (6.4 mm) is recommended. Gasoline can be forced out of the tank as a result of expansion if overfilled, and can affect the stable running condition of the generator.



Screw on the gasoline cap until you hear a "clicking" noise. Wipe up any spilled fuel.

A CAUTION

Use unleaded gasoline with a minimum octane rating of 85 and an ethanol content of 10% or less by volume.

DO NOT light cigarettes or smoke when filling the tank.

DO NOT mix oil and gasoline.

DO NOT overfill the tank. Fill tank to approximately $\frac{1}{4}$ in. (6.4 mm) below the top of the tank to allow for gasoline expansion.

DO NOT pump gasoline directly into the generator at the pump. Use an approved container to transfer the gasoline to the generator.

DO NOT fill tank indoors.

DO NOT fill tank when the engine is running or hot.

A WARNING

Pouring gasoline too fast through the fuel screen may result in gasoline splashing over the generator and operator while filling.

NOTICE

The generator engine works well with 10% or less ethanol blend gasoline. When using ethanol-gasoline blends there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor. The compromised gasoline can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- If a fuel stabilizer is used, confirm that it is formulated to work with ethanol-gasoline blends.
- Any damages or hazards caused by using improper gasoline, improperly stored gasoline, and/or improperly formulated stabilizers, are not covered by manufacturer's warranty.

It is advisable to always shut off the gasoline supply and run the engine to starvation after each use. See Storage instructions for extended non-use.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.

A WARNING

Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided (see Controls and Features for terminal location). For remote grounding, connect to a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

Neutral Floating*

- Neutral circuit IS NOT electrically connected to the frame/ ground of the generator.
- The generator (stator winding) is isolated from the frame and from the AC receptacle ground pin.
- Electrical devices that require a grounded receptacle pin connection will not function if the receptacle ground pin is not functional.

Neutral Bonded to Frame*

- Neutral circuit IS electrically connected to the frame/ground of the generator.
- The generator system ground connects lower frame crossmember below the alternator. The system ground is connected to the AC neutral wire.

OPERATION

Generator Location

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times. (Even while not in operation) Generators must have at least 5 ft. (1.5 m) of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least 3 ft. (91.4 cm) of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other

location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage.

Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

A WARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

A WARNING

During operation the muffler and exhaust fumes will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or enclosed, temperatures can become extremely heated and may lead to fire.

Surge Protection


Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

 Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment.
 Surge suppressors come in single- or multi-outlet styles.
 They're designed to protect against virtually all short-duration voltage fluctuations.


^{*}See your Specifications section for specified type of grounding.

Starting the Engine


- 1. Make certain the generator is on a flat, level surface.
- Disconnect all electrical loads from the generator. Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the fuel cap vent lever to the "ON" position.




4. Turn the fuel dial clockwise to the full "ON" position.




5. Pull choke knob out to the "CHOKE" position.



6. Pull the recoil cord slowly until resistance is felt and then pull rapidly.



As engine warms up, push the choke knob in to the "RUN" position.



NOTICE

Keep choke lever in "CHOKE" position for only 1 pull of the recoil cord. After first pull, press the choke knob in to the "RUN" position for up to the next 3 pulls of the recoil cord. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

NOTICE

For gasoline restarts with hot engine in hot ambient > 86°F (30°C): If generator does not start after the first pull, press the choke knob in to the "RUN" position for the next 3 pulls. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

NOTICE

For gas starting in cold ambient < 59°F (15°C): The choke must be in 100% of the "CHOKE" position for manual start procedures. Do not over-choke. As soon as engine starts, push the choke knob in the "RUN" position.

NOTICE

If the engine starts but does not continue to run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

Connecting Electrical Loads

Let the engine stabilize and warm up for a few minutes after starting.

Plug in and turn on the desired 120 or 240 (if applicable) Volt AC single phase, 60 Hz electrical loads.

- DO NOT connect 3-phase loads to the generator.
- DO NOT overload the generator.

A WARNING

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes:

- Select the electrical devices you plan on running at the same time.
- Total the running watts of these items. This is the amount of power you need to keep your items running.
- Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Starting wattage is the surge of power needed to start some electric driven equipment. Following the steps listed under

"Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts × Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- 1. Start the generator with no electrical load attached.
- 2. Allow the engine to run for several minutes to get up to temperature.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.


NOTICE

Never exceed the specified capacity when adding loads to the generator.

Eco (Economy) Mode

The Eco Mode button can be activated to turn on economy control in order to minimize fuel consumption and noise while operating the unit during times of reduced electrical output. Eco Mode allows the engine speed to idle during periods of non-use.

The engine speed returns to normal when an electrical load is connected. When the economy switch is off, the engine runs at normal speed continuously.



A CAUTION

For periods of high electrical load or momentary fluctuations, the Eco Mode should be off.

12V DC Automotive Style Outlet

The 12V DC outlet(s) can be used with supplied accessories and other commercially available 12V DC automotive style plugs. The DC output is unregulated and can damage some products. Confirm the input voltage range of your item is at least 12-24V DC. When using the DC outlet turn the Eco Mode switch to the "OFF" position.

A WARNING

Do not operate a device while it is plugged in to the 12V DC outlet.

Prolonged exposure to engine exhaust can cause serious injury or death.

A CAUTION

While charging a device do not place on the exhaust side of the generator. Extreme heat caused by exhaust can damage the device, and cause a potential fire hazard.

Battery Charging

- Before connecting the battery charging cable (included) to a battery that is installed in a vehicle, disconnect the vehicle battery ground cable from the negative (-) battery terminal.
- 2. Plug the battery charging cable into the 12V DC receptacle of the generator.
- Connect the red (+) battery charger lead to the red (+) battery terminal.
- 4. Connect the black (–) battery charger lead to the black (–) battery terminal.
- 5. Start the generator.

Important: The 12V DC outlet is ONLY to be used with the supplied 12V DC battery charging cable. The 12V DC output is unregulated and will damage other 12V DC products. When using the 12V DC outlet, turn the Economy mode switch to the "OFF" position. Be sure all electric devices including the lines and plug connections are in good condition before connection to the generator.

A CAUTION

Do not start the vehicle while the battery charging cable is connected and the generator is running. It will not give the battery a boost of power. The vehicle or the generator may be damaged. Charge only vented wet lead acid batteries. Other types of batteries may burst, causing personal injury or damage.

NOTICE

Be sure all electric devices including the lines and plug connections are in good condition before connection to the generator.


Parallel Operation

The Champion model 100889 is parallel ready and can be operated in parallel with another Champion unit to increase the total available electrical power. A Champion model 100319 parallel kit (optional equipment) is required for parallel operation. For a list of compatible models or to order a parallel kit, please call customer service at 1-877-338-0999 or visit www.championpowerequipment.com.

Detailed instructions for parallel kit installation and operation of the connected generators are provided in the parallel kit operator's manual.

Stopping the Engine

- 1. Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- 2. Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the fuel dial counter-clockwise to the STOP position.




Important: Always ensure that the fuel dial and fuel lever vent are in the "OFF" position when the generator is not in use.

NOTICE

If the generator will not be used for a period of two (2) weeks or longer, please see the Storage section for proper engine and fuel storage.

Moving the Generator

- ALWAYS turn the generator off and ensure the fuel valve is closed.
- ALWAYS make sure engine and muffler are cooled down before the generator can be handled safely (typically 15-30 minutes).
- Lift unit up by the carrying handle and move to the desired location.
- Do not drop or strike unit or place under heavy objects.
- Failure to follow these instructions could result in personal injury or damage to the generator.



Operation at High Altitude

The density of air at high altitudes is lower than at sea level. Engine power is reduced as the air mass and air-fuel ratio decrease. Engine power and generator output will be reduced approximately 3½% for every 1000 ft. of elevation above sea level. At high altitudes increased exhaust emissions can also result due to the increased enrichment of the air fuel ratio. Other high altitude issues can include hard starting, increased fuel consumption and spark plug fouling.

To alleviate high altitude issues other than the natural power loss, CPE can provide a high altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting our Technical Support Team. Installation instructions are also available in the Technical Bulletin area of the CPE website.

The part number and recommended minimum altitude for the application of the high altitude carburetor main jet is listed in the following table.

In order to select the correct high altitude main jet it is necessary to identify the carburetor model. For this purpose, a code is stamped on the side of the carburetor. Select the correct high altitude jet part number corresponding to the carburetor code found on your particular carburetor.

Carb. Code	High Alt. Jet Part Number	Min. Altitude
	100163549	3281 ft. (1000 m)
16169	100163550	6562 ft. (2000 m)

A WARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the originally supplied standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance.

MAINTENANCE

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

A WARNING

Never operate a damaged or defective generator.

A WARNING

Improper maintenance will void your warranty.

NOTICE

For Emission control devices and systems, read and understand your responsibilities for service as stated in the Emission Control Warranty Statement of this manual.

The owner/operator is responsible for all periodic maintenance.

Complete all scheduled maintenance in a timely manner.

Correct any issue before operating the generator.

For service or parts assistance, contact our Technical Support Team at 1-877-338-0999.

Cleaning the Generator

A CAUTION

DO NOT spray generator directly with water.

Water can enter the generator through the cooling slots and damage the generator windings. It can also contaminate the fuel system.


- 1. Use a damp cloth to clean exterior surfaces of the generator.
- 2. Use a soft bristle brush to remove dirt and oil.
- 3. Use an air compressor (25 PSI) to clear dirt and debris from the generator.
- 4. Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

To prevent accidental starting, remove and ground the spark plug wire before performing any service.


Changing the Engine Oil

Change oil when the engine is warm. Refer to the oil specification to select the proper grade for your operating environment.

- 1. Set the generator on top of a work bench or table.
- 2. Loosen the cover screws and remove the maintenance cover.
- 3. Remove oil fill cap/dipstick.



Tilt the generator on its side and allow the oil to drain completely.




- Add oil according to Add Engine Oil in Assembly section.
 DO NOT OVERFILL. Oil not included for routine maintenance.
- 6. Reinstall the maintenance cover.
- Dispose of used oil at an approved waste management facility.

NOTICE


Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

Cleaning and Adjusting the Spark Plug


- 1. Remove the maintenance cover.
- 2. Remove spark plug access cap from the top panel.



- 3. Remove the spark plug cable from the spark plug.
- 4. Use a spark plug socket tool (not included), or a 13/16 in. (21 mm) socket (not included) to remove the plug.




- 5. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 6. Make certain the spark plug gap is 0.024 0.031 in. (0.6 0.8 mm).



- Refer to the spark plug types in Specifications when replacing the plug.
- 8. Firmly re-install the plug.
- 9. Attach the spark plug cable to the spark plug.
- 10. Reinstall the spark plug access cap and maintenance cover.

Cleaning the Air Filter


- 1. Remove the maintenance cover.
- Locate the air filter plastic cover. Remove the screw using a Phillips head screwdriver.



- 3. Remove the foam element.
- 4. Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 5. Saturate in clean engine oil.
- 6. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 7. Place the filter in the assembly.
- 8. Reattach the air filter cover.
- Reinstall the maintenance cover and tighten the cover screw securely.

Cleaning the Spark Arrestor

- Allow the engine to cool completely before servicing the spark arrestor.
- 2. Remove the 6 screws holding the cover plate on the muffler side of the generator.
- Remove the screw which retains the spark arrestor to the muffler.
- 4. Remove the spark arrestor screen.
- Carefully remove the carbon deposits from the spark arrestor screen with a wire brush.



- 6. Replace the spark arrestor if it is damaged.
- 7. Position the spark arrestor on the muffler and attach by reversing the steps from above.

A CAUTION

Failure to clean the spark arrestor will result in degraded engine performance.

NOTICE

Federal and local laws and administrative requirements indicate when and where spark arrestors are required. When ordered, spark arrestors are required for operation of this generator in National Forest lands. In California, this generator must not be used on any forest-covered land, brush-covered land, or grass-covered land unless the engine is equipped with a spark arrestor.

Adjusting the Governor

A WARNING

Tampering with the factory set governor will void your warranty.

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. Contact our Technical Support Team at 1-877-338-0999 for all other service and/or adjustment needs.

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our Technical Support Team at 1-877-338-0999 to locate the nearest CPE certified service dealer for your generator or engine maintenance needs.

EVERY 8 HOURS OR PRIOR TO EACH USE
☐ Check oil level
☐ Clean around air intake and muffler
FIRST F HOURS (PREAK IN)
FIRST 5 HOURS (BREAK IN)
☐ Change oil
EVEDY TO HOUDE OR ANNUALLY
EVERY 50 HOURS OR ANNUALLY
☐ Clean air filter
☐ Change oil if operating under heavy load or in hot environments
EVERY 100 HOURS OR ANNUALLY
EVERY 100 HOURS OR ANNUALLY Change oil
☐ Change oil
☐ Change oil ☐ Clean/adjust spark plug
□ Change oil□ Clean/adjust spark plug□ Clean spark arrestor
□ Change oil□ Clean/adjust spark plug□ Clean spark arrestor
 □ Change oil □ Clean/adjust spark plug □ Clean spark arrestor □ Clean fuel valve filter*
☐ Change oil ☐ Clean/adjust spark plug ☐ Clean spark arrestor ☐ Clean fuel valve filter* EVERY 250 HOURS
 □ Change oil □ Clean/adjust spark plug □ Clean spark arrestor □ Clean fuel valve filter* EVERY 250 HOURS □ Clean combustion chamber*
 □ Change oil □ Clean/adjust spark plug □ Clean spark arrestor □ Clean fuel valve filter* EVERY 250 HOURS □ Clean combustion chamber*

STORAGE

A DANGER

Gasoline and gasoline vapors are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gasoline directly into the generator. Use an approved container to transfer the fuel to the generator. Never use a gasoline container, gasoline tank, or any other fuel item that is damaged or appears damaged. DO NOT overfill the gasoline tank. Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition.

DO NOT light or smoke cigarettes.

Short Term Storage (up to 30 days)

Gasoline in the gasoline tank has a maximum shelf life of up to 1 year with the addition of properly formulated fuel stabilizers and if stored in a cool, dry place. Gasoline in the carburetor, however, may gum up and clog the carburetor if it isn't used or drained within 2-4 weeks.

If using the generator within 2 weeks, follow the steps according to *Stopping the Engine* section.

- 1. If not using the generator for 2-4 weeks, begin by making sure all appliances are disconnected from the generator.
- 2. Start the generator as instructed in *Starting the Engine* section.
- 3. Let the engine run until fuel starvation has stopped the engine.
- 4. After the engine stops, turn the dial counterclockwise to the "STOP" position.

Mid Term Storage (30 days – 1 year)

Gasoline in the tank has a maximum shelf life of up to 1 year with the addition of a properly formulated fuel stabilizer and stored in a cool, dry place.


- 1. Be sure all appliances are disconnected from the generator.
- 2. Add a properly formulated fuel stabilizer to the gasoline tank.
- 3. Start engine by following directions in the *Starting the Engine* section.
- 4. Run the generator for 10 minutes so the treated gasoline cycles through the fuel system and carburetor.
- 5. Let the engine run until fuel starvation has stopped the engine.
- 6. After the engine stops, turn the dial counterclockwise to the "STOP" position.
- 7. After fuel has run out and the engine has stopped, allow the engine to cool.
- 8. Remove maintenance cover.
- 9. Remove the spark plug and pour about a tablespoon of oil into the cylinder.
- 10. SLOWLY pull the recoil to rotate the engine to distribute and lubricate the cylinder.
- 11. Re-install the spark plug and spark plug wire.
- 12. Re-install the maintenance cover.
- 13. Clean the generator according to *Cleaning the Generator*.
- 14. Store the generator in a cool, dry place out of direct sunlight.

^{*}To be performed by knowledgeable, experienced owners or CPE certified service centers.

Long Term Storage (more than 1 year)

For storage over 1 year, the gasoline tank and carburetor must be completely drained of gasoline.

- 1. Be sure all appliances are disconnected from generator.
- 2. Place inverter on blocks to allow appropriate gasoline container or pan to slide under inverter.
- 3. Remove the maintenance cover.
- 4. Turn the fuel dial clockwise to the full "RUN" position.
- Using a Phillips screwdriver, rotate drain screw counterclockwise (3) full turns. Gasoline will drain through clear tubing out underneath the inverter. Make sure draining gasoline empties into an appropriate container.



- 6. When gasoline stops flowing from the clear tube, rotate drain screw clockwise until tight. Properly dispose of the drained gasoline according to local regulations or guidelines.
- 7. Turn the fuel dial to the "STOP" position.
- 8. Follow steps 8-12 according to Short Term Storage.

Removing from Storage

If the generator has been improperly stored for a long period of time with gasoline in the gasoline tank and/or carburetor, all fuel must be drained and the carburetor must be thoroughly cleaned. This process involves technically advanced tasks. For assistance please call our Technical Support Team at 1-877-338-0999.

If the gasoline tank and carburetor were properly emptied of all gasoline prior to the generator being stored, follow the below steps when removing from storage.

- 1. Be sure the fuel dial is in the "STOP" position.
- 2. Add gasoline to the generator according to Add Fuel.
- 3. Move the fuel dial to the "RUN" position.
- 4. After 5 minutes check the carburetor and air filter areas for any leaking gasoline. If any leaks are found, the carburetor will need to be disassembled and cleaned or replaced. If no gasoline leaks are found, turn the fuel dial to the "STOP" position.
- 5. Check engine oil level and add clean, fresh oil if needed. See Oil Specifications for proper oil type.
- Check and clear air filter of any obstructions such as bugs or cobwebs. If necessary, clean air filter according to *Cleaning* the Air Filter.
- 7. Start the generator according to Starting the Engine.

A DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

 When storing the generator make sure the fuel dial is set to the "STOP" position.

SPECIFICATIONS

Generator Specifications

Generator Model	100889
Start Type	Manual
Watts (Starting/Running)	2500/1850
Volts AC	120
AC Amps @ 120V	15.4
Volts DC	12
DC Amps	8
Frequency	60 Hz
Phase	Single
Grounding Type	Floating Neutral
Weight	39.5 lb. (17.9 kg)
Length	17.3 in. (44 cm)
Width	11.5 in. (29.2 cm)
Height	17.7 in. (45 cm)

Engine Specifications

Model	148F-D
Displacement	79 cc
Type	4-Stroke OHV
Spark Plug	
OEM Type	TORCH E5T
Replacement Type	TORCH E6RTC or equivalent
Gap	0.024 - 0.031 in. (0.6 - 0.8 mm)
Valve	
Intake Clearance	0.004-0.006 in. (0.10-0.15 mm)

NOTICE


Exhaust Clearance 0.006-0.008 in. (0.15-0.20 mm)

A technical bulletin regarding valve adjustment procedures is available at www.championpowerequipment.com.

Oil Specifications

DO NOT OVERFILL.

Type	*See following chart
Capacity	16.9 fl. oz. (500 ml)



NOTICE

Temperature will affect engine oil and engine performance. Change the type of engine oil used based on the temperature to suit the engine needs.

Fuel Specifications

Use unleaded gasoline with a minimum octane rating of 85 and an ethanol content of 10% or less by volume. DO NOT USE E15 or E85. DO NOT OVERFILL.

Gasoline Capacity 1.1 gal. (4 L)


Temperature Specifications

Starting Temperature Range (°F/°C) 5 to 104/-15 to 40

NOTICE

An important message about temperature: Your product is designed and rated for continuous operation at ambient temperatures up to 104°F (40°C). When needed, it may be operated at temperatures ranging from 5°F (-15°C) to 122°F (50°C) for short periods of time. If exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and vents.

Parts Diagram




Parts List

2 100 3 100 4 100 5 100 6 100 7 100 8 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 19 100 20 100 21 100 21 100 22 100 23 100 24 100 25 100	0010946-0001 0095857-0005 0072724 0142156-0001 0088270 0010886-0004 0092320 0150096-0002 0150096-0001 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003 0011782	Screw M4 x 10 Bolt M4 x 18 Lever, Fuel Valve Panel Assembly Receptacle Cover GFCI 5-20R, Duplex Spring Washer Ø6 Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module Flat Washer Ø6	5 1 1 1 1 1 1 1 1 2 1 1 1 1 2 1	
3 100 4 100 5 100 6 100 7 100 8 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0072724 0142156-0001 0088270 0010886-0004 0092320 0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Lever, Fuel Valve Panel Assembly Receptacle Cover GFCI 5-20R, Duplex Spring Washer Ø6 Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 2 1 1 1 1 2 1	
4 100 5 100 6 100 7 100 8 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0142156-0001 0088270 0010886-0004 0092320 0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Panel Assembly Receptacle Cover GFCI 5-20R, Duplex Spring Washer Ø6 Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 1 1 1 1 1 2 1 1 2	
5 100 6 100 7 100 8 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0010886-0004 0092320 0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Receptacle Cover GFCI 5-20R, Duplex Spring Washer Ø6 Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 2 1 1 1 2 1 1 2 1 1	
6 100 7 100 8 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0010886-0004 0092320 0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	5-20R, Duplex Spring Washer Ø6 Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	2 1 1 1 1 2 1 1 2	
7 100 8 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0092320 0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Ground Stud Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 1 1 2 1 1 2	
8 100 9 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0150096-0002 0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003 0011025-0001	Cover, Parallel Terminal, Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 1 1 2 1 1 2	
9 100 10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0150096-0001 0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Black Cover, Parallel Terminal, Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 1 2 1 1 2	
10 100 11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0091059-0002 0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Red Parallel Terminal, Black Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 2 1 1 1 2	
11 100 12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0091059-0001 0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Parallel Terminal, Red Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 2 1 1 1 2 1	
12 100 13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0120180 0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	Cover, Circuit Breaker 20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	2 1 1 1 2 1	
13 100 14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0019747 0057719 0020029 0011421-0003 0142155 0010910-0003	20Amp Circuit Breaker, Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 1 2 1	
14 100 15 100 16 100 17 100 18 100 20 100 21 100 22 100 23 100 24 100 25 100	0057719 0020029 0011421-0003 0142155 0010910-0003 0011025-0001	Push Button 8Amp Circuit Breaker, Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 2 1	
15 100 16 100 17 100 18 100 19 100 20 100 21 100 22 100 23 100 24 100 25 100	0020029 0011421-0003 0142155 0010910-0003 0011025-0001	Push Button Receptacle 5-20R, Duplex Flange Nut M6 LED Display Module	1 2 1	
16 100 17 100 18 100 19 100 20 100 21 100 22 100 23 100 24 100 25 100	0011421-0003 0142155 0010910-0003 0011025-0001	Duplex Flange Nut M6 LED Display Module	2	
17 100 18 100 19 100 20 100 21 100 22 100 23 100 24 100 25 100	0142155 0010910-0003 0011025-0001	LED Display Module	1	
18 100 19 100 20 100 21 100 22 100 23 100 24 100 25 100	0010910-0003 0011025-0001			
19 100 20 100 21 100 22 100 23 100 24 100 25 100	0011025-0001	Flat Washer Ø6	0	
20 100 21 100 22 100 23 100 24 100 25 100		i	2	
21 100 22 100 23 100 24 100 25 100	nn19782	Lock Washer Ø6, Toothed	1	
22 100 23 100 24 100 25 100	0013702	Receptacle, 12 VDC	1	
23 100 24 100 25 100	0074968	Cable	1	
24 100 25 100	0083841	Switch Block		
25 100	0091757	Circlip, Bearing Holder, Ø1.8 x Ø6	ring Holder, 2	
	0081995	Step Bolt	16	
26 100)142063-0001	Housing, Front, Black	1	
20 1.00)126150	Fuel Valve, Angle 45°	1	
27 100	0011571-0001	Big Flange Bolt M6 x 14	lt M6 x 14 2	
	0005149	Clamp 1, Ø7.5	2	
29 100	0011570-0001	Big Flange Bolt M6 x 12 13		
30 100)159547	Inverter Module, 120V 60Hz	1	
31 100	0000671	Clip Ø13	1	
32 100	0011249-0003	Bolt M5 x 12	1	
33 1Z0	C7DFB05	Engine 79cc	1	
34 100	0033099-0006	Big Flange Bolt M6 x 18	2	
35 100		Tube Sheath, Silicon	1	
36 100)131884	Resin		

#	Part Number	Description	Qty.	
37	100090871	Clamp 2, Ø9.7 x 8	1	
38	100009020	Fuel Strainer	1	
39	100072874	Rear Air Guide	1	
40	100011004-0001	Self-tapping Screw ST4.2 x 25	4	
41	100092440-0007	Housing Assembly, Left Handle, Black	1	
42	100139137	Housing, Left Handle, Black	1	
43	100050562	Threaded Clamp	12	
44	100033079-0003	Screw M5 x 16	4	
45	100142060-0002	Housing Cover, Left, Yellow	1	
46	100081994	Shaft Locating Bolt	6	
47	100092446	Protection Ring, Starter Cord		
48	100072727	Rubber Pad	2	
49	100087371	Fuel Tank, 4 L	1	
50	100073150	Rubber Washer		
51	100008887	Lock Nut		
52	100072726-0001	Fuel Tank Cap		
53	100142062-0001	Housing, Rear, Black		
54	100072722	0-ring Seal		
55	100087972	Retainer Ring		
56	100011000-0001	Self-tapping Screw ST4.2 x 9.5		
57	100085794	Spark Arrester Assembly	1	
58	100072875	Front Air Guide	1	
59	100072878	Oil Seal		
60	100075041	Ignition Coil	1	
61	100093250-0005	Self-tapping Screw ST4.8 x 20	2	
62	100092441-0007	Housing Assembly, Right Handle, Black	1	
63	100139138	Housing, Right Handle, Black	1	
64	100092444-0005	Maintenance Cover, Top, Black	1	
65	100142057-0001	Housing Cover, Right, Yellow	1	
66	100142061-0001	Maintenance Cover, Yellow	1	
67	100146896	Washer, Maintenance Cover Knob	2	

#	Part Number	Description	Qty.	
68	100146895	Spring, Maintenance Cover Knob	2	
69	100146894-0001	Lever, Maintenance Cover Knob	2	
70	100142059-0001	Knob, Maintenance Cover	2	
71	100090005	Rectifier Bridge, Capacitance		
72	100072715	Vibration Mount, Support	4	
73	100088546	Housing Assembly, Bottom, Black		
74	100072711	Housing, Bottom, Black	, Black 1	
75	100072994	Step Nut M6	10	
76	100072710	Rubber Damper	1	
77	100011452-0003	Nut M6	4	
78	100072712	Foot, Bottom Housing	4	
79	100154370-0002	Maintenance Cover Assembly, Yellow		
80	100157108-0002	Housing Cover Assembly, Right, Yellow		
81	100134524	Screw	4	
82	100163194	Wiring Harness Assembly	1	

Engine Parts Diagram




Engine Parts List

#	Part Number	Description	Qty.	
1	100033099-0006	Big Flange Bolt M6 x 18	4	
2	100009386	Spark Plug(E5T)	1	
3	100154528	Breather Tube	1	
4	100072876	Cylinder Head Cover Assembly	1	
5	100085696	Strainer, Cylinder Head Cover	1	
6	100085695	Inner Cover, Cylinder Head Cover	1	
7	100005133	Cross Screw M3 x 6.5	3	
8	100075052	Gasket, Cylinder Head Cover	1	
9	100075054	Rocker Arm Assembly	2	
10	100075053	Shaft, Rocker Arm	1	
11	100075055	Valve Collet	2	
12	100075058	Oil Drip Pan	1	
13	100075056	Valve Spring Seat, 182F	2	
14	100159357	Spring Valve	2	
15	100011275-0002	Flange Bolt M6 x 50, GB5789		
16	100148916	Cylinder Head	1	
17	100088412	Stud Bolt M6 x 73	2	
18	100075043	Muffler Pad	1	
19	100065662	Exhaust Muffler Assembly	1	
20	100011277-0001	Flange Bolt M6 x 60, GB5789	4	
21	100011452-0003	Lock Nut M6, Flange	4	
22	100010348	Stud Bolt M6 x 87	2	
23	100075050	Gasket, Carburetor	1	
24	100075049	Insulator, Carburetor	1	
25	100075048	Gasket, Insulator	1	
26	100159122	Carburetor	1	
27	100061512	Stepper Motor	1	
28	100051029-0002	Screw M4 x 6	2	
29	100005149	Clamp 1, Ø7.5	1	
30	100087351	Oil Tube	1	
31	100075035	Air Filter Hose	1	
32	100085694	Gasket, Cylinder Head	1	
33	100010549	Dowel Pin Ø8 x 12	4	
34	100075061	Push Rod	2	
35	100075059	Valve Exhaust	1	
36	100159354	Valve Intake	1	

#	Part Number	Description	Qty.	
37	100075036	Lifter, Valve	2	
38	100075040	Piston Ring Set	1	
39	100088147	1st Piston Ring	1	
40	100088148	2nd Piston Ring	1	
41	100088146	Oil Ring	1	
42	100075038	Circlip	2	
43	100075039	Wrist Pin	1	
44	100159355	Piston	1	
45	100075037	Connecting Rod	1	
46	100091043	Bolt, Connecting Rod	2	
47	100085410	Crankcase	1	
48	100075063	Oil Level Sensor	1	
49	100031967-0007	Big Flange Bolt M6 x 16	2	
50	100011570-0001	Big Flange Bolt M6 x 12	5	
51	100065663	Crankshaft	1	
52	100159356	Camshaft	1	
53	100075062	Gasket, Crankcase Cover	1	
54	100072617	Cover, Crankcase	1	
55	100031968-0002	Big Flange Bolt M6 x 20		
56	100084322-0003	Oil Dipstick Assembly, Black	1	
57	100092649	Trigger	1	
58	100085697	Oil Seal Ø20 x Ø32 x 6	1	
59	100159546	Alternator Assembly, Ø150 x 44.5 mm	1	
60	100159545	Stator Assembly, Fe, Ø120 x 21 mm	1	
61	100085871	Rotor Assembly, Permanent Magneto, Ø150 x 44.5 mm	anent Magneto, 1	
62	100011223-0001	Flange Bolt M6 x 32	2	
63	100072871	Cooling Fan	1	
64	100072872	Pulley, Starter	1	
65	100033063-0001	Flange Nut M12 x 1.25	1	
66	100072873	Fan Cover Assembly	1	
67	100085054	Fan Cover, Black	1	
68	100075483	Air Filter Element	1	
69	100075482	Air Filter Cover	1	
70	100000655	Wire Clip B	1	
71	100075051-0001	Recoil Starter Assembly, Black	1	
72	100011571-0001	Big Flange Bolt M6 x 14	3	
73	100072994	Step Nut M6	2	

#	Part Number	Description	Qty.
74	100131960	Fuel Bowl O-Ring	1
	100163552	Main Jet Standard	1
75	100163549	Main Jet Altitude 1000-2000m	/
	100163550	Main Jet Altitude 2000-3000m	/
76	100006037	Fuel Bowl Mounting Bolt Gasket	1
77	100131964	Fuel Bowl Mounting Bolt	1

Wiring Diagram



TROUBLESHOOTING

Problem	Cause	Solution
	No fuel.	Add fuel.
	Faulty spark plug.	Clean and adjust spark plug or replace.
	Laurail laura	Fill crankcase to the proper level.
Engine will not stort	Low oil level.	Place generator on a flat, level surface.
Engine will not start.	Spark plug wire loose.	Attach wire to spark plug.
	Fuel valve is closed.	Open fuel valve.
	Old fuel or water in fuel.	Drain fuel and replace with fresh fuel.
	Flooded with fuel.	Let unit stand for 10 mins.
	Choke in the wrong position.	Move choke until it stops under RUN position or push in completely.
Engine starts but runs roughly.	Dirty air filter.	Clean or replace air filter.
	Dirty fuel valve.	Clean the fuel valve.
	Clogged spark arrestor.	Clean spark arrestor.
	Out of fuel.	Fill fuel tank.
Engine shuts down during operation.	Low oil level.	Fill crankcase to the proper level. Place generator on a flat, level surface.
	Clogged spark arrestor.	Clean spark arrestor.
	Generator is overloaded.	Review load and adjust. See "Connecting Electrical Loads."
Generator cannot supply enough power	Dirty air filter.	Clean or replace air filter.
or overheating.	Choke in wrong position.	Move choke until it stops under RUN position or push in completely.
	Poor cord connection.	Check all connections.
Engine is rupping but no AC output	Circuit breaker is open.	Reset circuit breaker.
Engine is running but no AC output.	Loose wiring.	Inspect and tighten wiring connections.
	Other.	Contact the help line.
	Engine governor defective.	Contact the help line.
	Dirty fuel valve.	Clean the fuel valve.
Engine hunts or falters.	Carburetor is dirty and running lean.	Contact the help line.
	Choke in wrong position.	Move choke until it stops under RUN position or push in completely.
	Overload.	Review load and adjust. See "Connecting Electrical Loads."
		Observation demonstrated beautiful formation and production of Development
Repeated circuit breaker tripping.	Faulty power cords or device.	Check for damaged, bare or frayed wires. Replace defective device.

For other issues and technical support:

Technical Support Team Mon-Fri 8:30 AM-5:00 PM (PST/PDT) Toll Free 1-877-338-0999 support@championpowerequipment.com

WARRANTY*

CHAMPION POWER EQUIPMENT 3 YEAR LIMITED WARRANTY

Warranty Qualifications

To register your product for warranty and FREE lifetime call center technical support please visit:

https://www.championpowerequipment.com/register

To complete registration you will need to include a copy of the purchase receipt as proof of original purchase. Proof of purchase is required for warranty service. Please register within ten (10) days from date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of three years (parts and labor) from the original date of purchase and 270 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product.

THIS WARRANTY AND THE ATTACHED U.S. EPA and/or CARB EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICUL AR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

Customer Service

Mon – Fri 8:30 AM – 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

info@championpowerequipment.com

Fax no.: 1-562-236-9429

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

^{*}Except as otherwise stipulated in any of the following enclosed Emission Control System Warranties (when applicable) for the Emission Control System: U.S. Environment Protection Agency (EPA) and/or California Air Resources Board (CARB). Whichever warranty applies for the longer period, either this 3 year limited warranty or the applicable Emission Control System Warranty, shall supersede the other.

CHAMPION POWER EQUIPMENT, INC. (CPE), THE UNITED STATES ENVIRONMENTAL PROTECTION AGENCY (U.S. EPA) AND THE CALIFORNIA AIR RESOURCES BOARD (CARB) EMISSION CONTROL SYSTEM WARRANTY

Your Champion Power Equipment (CPE) engine complies with both the U.S. EPA and state of California Air Resources Board (CARB) Exhaust and Evaporative emissions regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The US EPA, California Air Resources Board, and CPE are pleased to explain the Federal and California Exhaust and Evaporative Emission Control Systems Warranty on your 2020 small off-road engine (SORE) and engine powered equipment. In California, new equipment that use small off-road engines (SORE) must be designed, built and equipped to meet the State's stringent anti-smog standards.

CPE must warrant the exhaust and evaporative emission control system on your small off-road engine (SORE) for the period listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your equipment leading to the failure of the exhaust and evaporative emission control systems.

Your evaporative emission control system may include parts such as: carburetors, fuel tanks, fuel lines, (for liquid fuel and fuel vapors), fuel caps, valves, canisters, filters, clamps, connectors, and other associated components. Also included for your exhaust emission control system may be the fuel-injection system, the ignition system, catalytic converter and other exhaust emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine (SORE) at no cost to you including diagnosis, parts and labor.

MANUFACTURER'S WARRANTY COVERAGE:

This exhaust and evaporative emission control system is warranted for two years. If any exhaust and evaporative, emission related part on your engine or equipment is defective in, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine (SORE) owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine (SORE), but CPE cannot deny warranty coverage solely for the lack of receipts.

As the small off-road engine (SORE) owner, you should be aware that CPE may deny you warranty coverage if your small off-road engine (SORE) or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE distribution center, service center or alternate service outlet as described in (3)(f) below or CPE dealer or CPE, Santa Fe Springs, Ca. as soon as the problem exists. The warranty repairs shall be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty coverage, you should contact:

Champion Power Equipment, Inc.
Customer Service
12039 Smith Ave.
Santa Fe Springs, CA 90670
1-877-338-0999
tech@championpowerequipment.com

EXHAUST AND EVAPORATIVE EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Exhaust and Evaporative Emission Control System (ECS) Warranty Coverage.

 APPLICABILITY: This warranty shall apply to 1995 and later model year California small off-road engines (SORE) (for other states, 1997 and later model year engines). The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines (SORE) is:

- 2a. Designed, built and equipped to conform to U.S. EPA emissions standards for spark-ignited engines at or below 19 kilowatts and all applicable regulations adopted by the California Air Resources Board and
- 2b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EXHAUST AND EVAPORATIVE EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- 3a. Any warranted part that is not scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- 3b. Any warranted, exhaust and evaporative emissions-related part which is scheduled only for regular inspection as specified in the Owner's Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- 3c. Any warranted, exhaust and evaporative emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such exhaust and evaporative emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- 3d. Repair or replacement of any warranted, exhaust and evaporative emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- 3e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- 3f. CPE shall pay for covered exhaust and evaporative emissions warranty repairs at non-authorized service outlets under the following circumstances:
 - i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
 - ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100 mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- 3g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- 3h. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted exhaust and evaporative emission-related parts sufficient to meet the expected demand for such exhaust and evaporative emission-related parts.
- 3i. Any CPE Authorized and approved exhaust and evaporative emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- 3j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Carburetor and internal parts (and/or pressure regulator or fuel injection system), Air/fuel ratio feedback and control system, Cold start enrichment system.
Air Induction System	Controlled hot air intake system, Intake manifold, Air filter.
Ignition System	Spark plug, Magneto or electronic ignition system, Spark advance/retard system.
Exhaust Gas Recirculation (EGR) System	EGR valve body, and carburetor spacer if applicable, EGR rate feedback and control system.
Air Injection System	Air pump or pulse valve, Valves affecting distribution of flow, Distribution manifold.
Catalyst or Thermal Reactor System	Catalytic Converter, Thermal Reactor, Exhaust Manifold.
Particulate Controls	Traps, Filters, Precipitators, and any other device used to capture particulate emissions.
Miscellaneous items used in Above Systems	Vacuum, Temperature, and time sensitive valves and switches, Electronic Controls, Hoses, Belts, Connectors, and Assemblies.
Evaporative Controls	Fuel Tank, Fuel Cap, Fuel Lines (for liquid fuel and fuel vapors), Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Gaskets, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector.

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Alternate service locations defined in Section (3)(f) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc.

12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999

Attn.: Customer Service tech@championpowerequipment.com