

Operator Manual Home Standby Power Generator Set

GSBA (Spec A-B)

Table of Contents

1.	IMPORTANT SAFETY INSTRUCTIONS	1
	1.1 Save These Instructions	1
	1.2 General Precautions	1
	1.3 Generator Voltage is Deadly	2
	1.4 Engine Exhaust is Deadly	2
	1.5 Fuel is Flammable and Explosive	2
	1.6 Batteries Can Explode	2
	1.7 Moving Parts Can Cause Severe Personal Injury or Death	3
	1.8 The Hazards of Carbon Monoxide	3
	1.8.1 What Is Carbon Monoxide Poisoning?	3
	1.8.2 What Are the Special Risks of CO Near the Home?	3
	1.8.3 Only You Can Protect Yourself From CO Poisoning!	4
2	INTRODUCTION	5
۷.	2.1 About this Manual	5
	2.2 About the Generator Set	5
	2.3 Model Specifications	6
	2.4 Generator Set Nameplate	8
	2.5 How to Obtain Service	9
3.	OPERATION	11
	3.1 3 Position Switch	11
	3.2 Home Operator Panel	12
	3.2.1 BACK Button	12
	3.2.2 START STOP Button	12
	3.2.3 Standby ON/OFF Button	12
	3.3 Typical Operation	13
	3.3.1 Normal Operation: Utility Power Available and Connected	16
	3.3.2 Emergency Operation: Utility Power Interrupted	17
	3.3.3 To Adjust the Output Voltage	18
	3.4 To Enable/Disable Standby	18
	3.5 To Manually Start/Stop Generator Set	19
	3.6 Fault, Maintenance and New Event Screens	19
	3.6.1 Fault Screen	20
	3.6.2 Maintenance Due Screen	20
	3.6.3 New Event Screen	20
	3.7 Exercise Settings	21
	3.8 Time Setup	22
	3.9 Load Management	23
	3.9.1 Automatic Load Management	23
	3.9.2 Manual Load Management	23
	3.10 Genset Status	24

	3.11 Display Setup and Software Info	25
	3.11.1 Brightness and Contrast	25
	3.11.2 Software Info	26
	3.12 Event Log	27
	3.12.1 To Check Log of Last 20 Events	27
	3.12.2 List of Recordable Events	27
	3.13 Fault Log	28
4.	MAINTENANCE	31
	4.1 Periodic Maintenance Schedule	31
	4.2 Cleaning the Housing Top	32
	4.3 Exercising the Generator Set	32
	4.4 Engine Oil Maintenance	32
	4.4.1 Recommended Engine Oil	32
	4.4.2 Checking Engine Oil Level	32
	4.4.3 Add or Drain Oil	33
	4.4.4 Changing Engine Oil and the Oil Filter	33
	4.5 Replacing the Air Filter Element	34
	4.6 Battery Maintenance	35
	4.7 Spark Plugs	36
	4.8 Maintenance Record	36
5.	TROUBLESHOOTING	39
	5.1 Troubleshooting With the In-Home Operator Panel	39
	5.2 Fault Code Blinking	39
	5.3 Restoring Fault Code Blinking	39
	5.4 Troubleshooting with the Flashing Indicator Light	40
	5.4.1 Starting Battery Runs Down	40
	5.4.2 No Response - Status Indicator Light Dead	40
	5.4.3 Starter Engages - Disengages	40
	5.4.4 No AC Power - Generator Set Running, Status LED On Steady or Flashing Rapidly	41
	5.4.5 Generator Set Cranks But Does Not Start - No Fault Code	41
	5.4.6 Genset Warning - Transfer Switch Failed to Transfer to Utility - No Fault Code	41
	5.4.7 Low Oil Pressure Fault - Fault Code 2	41
	5.4.8 Overcrank - Fault Code 4	41
	5.4.9 Overvoltage - Fault Code 12	42
	5.4.10 Undervoltage - Fault Code 13	42
	5.4.11 Overfrequency - Fault Code 14	42
	5.4.12 Underfrequency - Fault Code 15	42
	5.4.13 Governor Actuator shutdown - Fault Code 19	42
	5.4.14 Governor Actuator Overload - Fault Code 22	43
	5.4.15 Voltage Sense Lost - Fault Code 27	43
	5.4.16 High Battery Voltage - Fault Code 29	43
	5.4.17 Low Cranking Speed Sense - Fault Code 32	43
	5.4.18 Control Card Failure - Fault Code 35	43

11-2015 Table of Contents

	5.4.19 Generator Set Stopped Without Fault Condition - Fault Code 36	44
	5.4.20 Invalid Set Configuration - Fault Code 37	44
	5.4.21 Processor Fault - Fault Code 43	44
	5.4.22 Speed Sense Fault - Fault Code 45	44
	5.4.23 Generator Set Overload - Fault Code 46	44
	5.4.24 Alternator Over Temp - Fault Code 76	44
	5.4.25 Low Fuel Pressure - Fault Code 78	45
	5.4.26 Failure To Transfer To Generator Set - Fault Code 79	45
	5.5 Communication Troubleshooting	45
	5.5.1 In-Home Network Access to Generator Set Troubleshooting	45
	5.5.2 Remote Internet Access to Generator Set Troubleshooting	46
	5.5.3 Email Alert Troubleshooting	47
6	OPTIONAL INTERNET/EMAIL INTERFACE DESCRIPTIONS	51
Ο.	6.1 Introduction	51
	6.2 Screen Descriptions	52
	6.2.1 Setting Time and Date	52
	6.2.2 Set Exercise Schedule	52
	6.2.3 Load Control (Management)	53
	6.2.4 Event Log	53
	6.2.5 Fault Log	54
	6.2.6 Network Setup Screen Descriptions	54
	6.2.7 Email Setup Screen Descriptions	55
	6.2.8 Saving Changes	56
	6.3 Ethernet Connections (Optional)	56

A029V091 (Issue 6) iii

Table of Contents 11-2015

This page is intentionally blank.

1 IMPORTANT SAFETY INSTRUCTIONS

1.1 Save These Instructions

This manual contains important instructions for the generator set that should be followed during the operation and maintenance of the generator and batteries.

Thoroughly read this manual before operating the generator set. Safe operation and top performance can only be obtained when equipment is properly operated and maintained.

The following symbols in this manual alert you to potential hazards to the operator, service person and equipment.

▲ DANGER

Alerts you to an immediate hazard that will result in severe personal injury or death.

⚠ WARNING

Alerts you to a hazard or unsafe practice that can result in severe personal injury or death.

CAUTION

Alerts you to a hazard or unsafe practice that can result in personal injury or equipment damage.

1.2 General Precautions

- · Keep ABC fire extinguishers handy.
- Make sure all fasteners are secure and torqued properly.
- Keep the generator set and its compartment clean. Do not store any items in the genset compartment.
 - Excess oil, oily rags (etc.) can catch fire.
 - Dirt and gear stowed in the compartment will restrict cooling air flow.
- Before working on the generator set, move the Stop Switch (S2) to the Stop position, disconnect the remote harness (P7) to disable the ATS mounted charger and then remove the negative (–) battery cable to prevent starting.
- Use caution when making adjustments while the generator set is running, hot, moving or when parts are electrically live, as all situations may cause personal injury or death.
- Used engine oil has been identified by some state and federal agencies as causing cancer
 or reproductive toxicity. Do not ingest, inhale or come into contact with used oil or its
 vapors.
- Do not work on the generator set when mentally or physically fatigued or after consuming alcohol or drugs.

1.3 Generator Voltage is Deadly

- Generator output connections must be made by a trained and experienced electrician in accordance with all applicable codes.
- This standby generator set and the public utility may only be connected to the house circuits by means of the model RSS Automatic Transfer Switch.
 - Improper connections can lead to electrocution of utility workers and damage to equipment.
- Use caution when working on live electrical equipment. Remove jewelery, make sure clothing and shoes are dry and stand on a dry wooden platform.

1.4 Engine Exhaust is Deadly

- See <u>What is Carbon Monoxide Poisoning</u> to learn the symptoms of Carbon Monoxide poisoning.
- This generator set is for out-door installation only.
 - It must be located well away from doors, windows, other openings into the house and where the exhaust gases will disperse away from the house.

1.5 Fuel is Flammable and Explosive

- Keep flames, cigarettes, sparks, pilot lights, electrical arc-producing equipment, switches
 and all other sources of ignition well away from areas where fuel fumes are present and
 areas sharing ventilation.
- Fuel lines must be secured, free of leaks and separated or shielded from electrical wiring.
- Leaks can lead to explosive accumulations of gas. Prevent leaks and the accumulation of gas.
 - A "rotten egg" smell indicates a possible Natural Gas or Propane leak:
 - Natural Gas rises when released and can accumulate under hoods and inside housings and buildings.
 - Propane sinks when released and can accumulate inside housings and basements and other below-grade spaces.

1.6 Batteries Can Explode

Batteries can explode, causing severe skin and eye burns and can release toxic electrolytes.

- · Wear safety glasses.
- · Do not smoke.
- Do not dispose of the battery in a fire.
 - · The battery is capable of exploding.

- Do not open or mutilate the battery.
 - Released electrolytes have been known to be harmful to the skin and eyes and to be toxic.
- Batteries present the risk to high short circuit current:
 - Remove watches, rings or other metal objects and use tools with insulated handles.
- To prevent arcing when disconnecting the battery:
 - Move the Stop Switch (S2) to the Stop position, disconnect the remote harness (P7) to disable the ATS mounted charger and then remove the negative (-) battery cable to prevent starting.
- To prevent arcing when reconnecting the battery:
 - First, reconnect the positive (+) cable, then the negative (-) cable, and finally reconnect the battery charger.
- When replacing the generator set battery, always replace it with a battery as specified in the **Model Specifications** section of this manual.

1.7 Moving Parts Can Cause Severe Personal Injury or Death

- Do not wear loose clothing or jewelry near moving parts such as fans.
- · Keep hands away from moving parts.
- · Keep guards in place, over fans.

1.8 The Hazards of Carbon Monoxide

Engine-driven generators can produce harmful levels of carbon monoxide that can injure or kill you.

1.8.1 What Is Carbon Monoxide Poisoning?

Carbon Monoxide (CO) is an odorless, colorless, tasteless and non-irritating gas. You cannot see it or smell it. Red blood cells, however, have a greater affinity for CO than for Oxygen. Therefore, exposure even to low levels of CO for a prolonged period can lead to asphyxiation (lack of Oxygen) resulting in death. Mild effects of CO poisoning include eye irritation, dizziness, headaches, fatigue and the inability to think clearly. More extreme symptoms include vomiting, seizures and collapse.

1.8.2 What Are the Special Risks of CO Near the Home?

Residents can be exposed to lethal levels of CO when the genset is running. Depending on air temperature and wind, CO can accumulate in or near the home.

To protect yourself and others from the dangers of CO poisoning, it is recommended that reliable and approved CO detector alarms be installed in the home.

⚠ WARNING

Carbon Monoxide (CO) gas can cause nausea, fainting or death.

1.8.3 Only You Can Protect Yourself From CO Poisoning!

- Locate the generator in an area where there are no windows, doors or other access points into the home.
- Make sure all CO detectors are working properly.
- · Pay attention to the signs of CO poisoning.
- Check the exhaust system for corrosion, obstruction and leaks each time you start the generator set and every eight hours if you run it continuously.

2 Introduction

This generator set application is intended for stationary emergency use.

Important note for Brazil applications: The manufacturer warns that the installation, operation and maintenance of equipment by the user must fully comply with the Manual's guidelines and current Brazilian laws, including those of the Brazilian Agency of Petroleum, Natural Gas and Fuels (ANP) and the Brazilian Energy Agency (ANEEL).

2.1 About this Manual

This is the Operator Manual for the generator set. Each operator of this generator set should become thoroughly familiar with the information in this manual and observe all of its instructions and precautions.

Refer to the **Operation** chapter of this manual for instructions and guidelines for operating and monitoring the genset.

Refer to the <u>Maintenance</u> chapter of this manual for instructions and guidelines for performing periodic maintenance. The operator is responsible for generator set maintenance in accordance with the Periodic <u>Maintenance Schedule</u>.

⚠ WARNING

This generator set is not for life support. It can stop without warning. Children, persons with physical or mental limitations, and pets could suffer personal injury or death. A personal attendant, redundant power or an alarm system must be used if power system operation is critical.

2.2 About the Generator Set

The generator set is an engine-powered generator set fueled by Natural Gas or Propane. It is for installation as a standby generator set only, in conjunction with the model RSS Automatic Transfer Switch produced under the Cummins® Power Generation brand name.

See the Specifications section of this manual for specific information about the generator set.

A CAUTION

It is recommended that this model generator set be installed with the model RSS Automatic Transfer Switch by a trained and experienced electrician or authorized Cummins Power Generation service representative.

The generator set is intended as a back-up to utility power. Whenever utility power is interrupted, the house electrical loads are automatically switched by the transfer switch from the utility (normal power source) to the generator set (emergency power source). When utility power is restored, the loads are automatically switched back to the utility. To do this, the generator set and transfer switch perform the following functions together:

- 1. Senses an interruption of utility power.
- 2. Starts the generator set.
- 3. Transfers the load to the generator set when operation has stabilized.

2. Introduction 11-2015

- 4. Senses the return of utility power.
- 5. Retransfers the load to the utility.
- 6. Stops the generator set.

A more in-depth illustration of the operation of the generator set and transfer switch can be found in the Timing Charts, located in the **Typical Operation** section of this manual.

2.3 Model Specifications

The generator set consists of three model variations. These variations are defined in the table below.

TABLE 1. MODEL VARIATIONS

Product	Description
13GSBA-6712	60 Hz Warm
13GSBA-6711	60 Hz Cold*
13GSBA-6718	60 Hz CSA*

^{*} Includes an alternator dryer, oil heater kit, and intake warmer.

See the Cold Weather Specifications Table for recommendations.

TABLE 2. COLD WEATHER SPECIFICATIONS TABLE

Operating Temperature Range	
Above 32° F (0° C) and low humidity	No dryers or starting aids required.
Any temperature with high humidity	Alternator drying heater recommended.
Below 32° F (0 °C)	Additional oil and intake heater recommended for starting. Factory installed model available.
Below -10° F (-23 °C)	Additional accessory battery blanket recommended for starting.

TABLE 3. GENERATOR SET SPECIFICATIONS TABLE

Dimensions	
Weight (With Oil)	460 lbs (209 kg)
Size (L x W x H)	48 x 43 x 34.6 in (1219 x 864 x 880 mm)
Noise	64 dB(A) at 23 ft (7 m) at normal load.

11-2015 2. Introduction

TABLE 4. FUEL SPECIFICATIONS TABLE

Fueling	Propane Vapor	Natural Gas
1/2 Load	132,500 Btu/Hr 53 ft³/Hr	122,000 Btu/Hr 122 ft³/Hr
Full Load	220,000 Btu/Hr 88 ft³/Hr	191,000 Btu/Hr 191 ft³/Hr
Fuel Pressure	7-11 inches WC	5-11 inches WC
Tank Size 500 Gallon (Contact your local gas company to verify the your application).		al gas company to verify the tank size required for

TABLE 5. GENERATOR SPECIFICATIONS TABLE

Fuel Type	Propane Vapor	Natural Gas
Generator	Brush-Type, 2-Pole Rotating Field, Single	Bearing
Rated Voltage (V)	120/240	120/240
Rated Current (Amps)	106/53	92/46
Phase Type	Single Phase	
Circuit Breaker (Amps)	60	60

De-rating Guidelines: Maximum wattage or maximum current are subject to and limited by such factors as fuel Btu content, ambient temperature, altitude, engine power and conditions, etc. Full-rated power is available at 60 °F (15.5 °C) at sea level. De-rate 3.5% for each 1000 ft. (304.8 m) above sea level and 3% for each 10 °F (5.5 °C) increase in ambient temperature above 60 °F (15.5 °C). This generator is rated in accordance with UL 2200 (Stationary Engine Generator Assemblies) or CSA C22.2 No. 100-04 (Motors and Generators). The maximum continuous current values that are listed on the generator set nameplate and specification tables occur at the lower limit of acceptable voltage. Maximum current occurs at 108 and 216 volts, 10% below nominal voltage 120/240. The voltage set point of this generator set can be adjusted from the operator panel if desired. Refer to the Operator Manual procedure To Adjust the Output Voltage.

TABLE 6. ENGINE SPECIFICATIONS TABLE

Engine	2 Cylinder-V Twin, OHV, Air-Cooled, 4-Stroke, Spark Ignited, 3600 RPM
Displacement	720 cc
Spark Plug Gap	0.7 to 0.8 mm
Spark Plug Torque	10 ft-lb (13.5 N-m)
Cylinder Leak Down Pressure	75 PSI (517 kPa)
Intake and Exhaust Valve Lash (Measure at 0.25" (6.35mm) past top dead center)	0.07 to 0.13 mm
Oil Capacity	1.7 quarts (1.6L)
Oil Recommendation (See Operator Manual)	5W-30 Synthetic Engine Oil (Mobil 1)
Cylinder Compression	170 PSI (12 kg/cm²) @ 470 rpm

2. Introduction 11-2015

TABLE 7. CONTROL SPECIFICATIONS TABLE

Controller	Integrated Microprocessor-Based Engine, Generator, Transfer Switch Controller

TABLE 8. DC SYSTEM SPECIFICATIONS TABLE

DC System	
Nominal Battery Voltage	12 Volts DC
Battery Group	26 R
Battery Type	Maintenance Free
Minimum Cold Crank Amps	545

2.4 Generator Set Nameplate

⚠ WARNING

Improper service or replacement of parts can lead to severe personal injury or death and to damage to equipment and property. Service personnel must be qualified to perform electrical and mechanical service.

⚠ CAUTION

Unauthorized modifications or replacement of fuel, exhaust, air intake or speed control system components that affect engine emissions are prohibited by law in the State of California.

Model, Spec and Serial Numbers: Be ready to provide the model, spec and serial numbers on the generator set nameplate when contacting Cummins Power Generation for information, parts and service.

Record these numbers so that they are easy to find when needed. Each character in these numbers is significant for obtaining the right parts listed in the Parts Catalog. Genuine Cummins Power Generation replacement parts are recommended for best results.

My Generator Set Information	
Model	
Spec	
Serial Number	

11-2015 2. Introduction




FIGURE 1. NAMEPLATE

2.5 How to Obtain Service

For parts, service, and product information (such as the Service Manual), contact the nearest authorized Cummins Power Generation distributor. You may go to Web site www.power.cummins.com for information on contacting our distributors worldwide.

In North America

Call 1-800-888-6626 to contact the nearest Cummins Power Generation distributor in the United States or Canada. If you are unable to contact a distributor using the automated service, consult the Yellow Pages. Typically, our distributors are listed under:

GENERATORS - ELECTRIC

ENGINES - GASOLINE OR DIESEL

If you have difficulty arranging service or resolving a problem, please contact the Service Manager at the nearest Cummins Power Generation distributor for assistance.

Outside North America

If you are outside North America, call Cummins Power Generation at 1-763-574-5000 from 7:30 AM to 4:00 PM, Central Standard Time, Monday through Friday.

Information to Have Ready

Before calling for service, have the following information available:

- 1. Complete model number and serial number
- 2. Date of purchase
- 3. Nature of problem

2. Introduction 11-2015

This page is intentionally blank.

3 Operation

3.1 3 Position Switch

A three-position Start/Stop switch is located at the genset control panel.

Switch positions available:

- Manual Start: Normally only the maintenance/service technician has occasion to manually start and stop the generator set. Push the switch down at the thick end to start the set immediately.
- Stop (middle position): This switch disables the set.
- Remote: For automatic operation, the Start/Stop switch must be in the Remote position and Standby On must be activated on the In-Home Display. Push the switch down at the thin end to put into the Remote position.




FIGURE 2. 3 POSITION SWITCH (STOP SWITCH)

3.2 Home Operator Panel

The operator panel must be hard-wired to the generator set in order for the generator system to operate.

NOTICE

The in-home operator panel and Internet/Email interface can be used simultaneously

The operator panel consists of two UTILITY status lamps, three GENERATOR status lamps, three action buttons and an LCD display screen with four navigation buttons.




FIGURE 3. IN-HOME OPERATOR PANEL

3.2.1 BACK Button

When navigating through the LCD menus, press the **BACK** button to return to the main operating screen.

3.2.2 START STOP Button

See To Manually Start/Stop Generator Set.

3.2.3 Standby ON/OFF Button

See To Enable/Disable Standby.

3.3 Typical Operation

NOTICE

The following diagrams are based on an APPROXIMATE time duration. Your genset may vary slightly from the timing diagrams in this manual.




FIGURE 4. TYPICAL POWER OUTAGE CYCLE TIMING DIAGRAM




FIGURE 5. EXERCISE TIMING DIAGRAM




FIGURE 6. MANUAL START/STOP TIMING DIAGRAM




FIGURE 7. LOAD MANAGEMENT TIMING DIAGRAM

3.3.1 Normal Operation: Utility Power Available and Connected

As long as utility power is available and connected, both of the green UTILITY lamps (PRESENT and CONNECTED) will stay on and the LCD screen will indicate "Genset Stopped".

If the red GENERATOR STANDBY OFF light is on, the generator set will not start up automatically if utility power is interrupted. See the <u>To Enable/Disable Standby</u> section of this manual to enable STANDBY so that the generator set will automatically supply power if utility power is interrupted.




FIGURE 8. UTILITY PRESENT AND CONNECTED—STANDBY OFF LAMP ON

3.3.2 Emergency Operation: Utility Power Interrupted

If utility power is interrupted,

- 1. The green UTILITY PRESENT lamp will go out
- 2. The generator set will start automatically and the green GENERATOR RUNNING lamp will turn on.
- 3. The UTILITY CONNECTED light will go out when the generator set is connected to supply power.

The LCD screen will provide a visual indication of "Genset Load" (bar graphs). The bar graphs indicate how much of the available power is being used in each supply line (L1 and L2).

If the red ACTION REQUIRED light comes on, either the generator shut down or periodic maintenance has come due. The LCD screen will indicate what maintenance is due or which fault occurred.




FIGURE 9. GENERATOR SET RUNNING—ACTION REQUIRED LAMP ON

3.3.3 To Adjust the Output Voltage

Use the following procedure:

- 1. Connect an accurate AC volt meter across L1 and L2 while the generator set is running.
- 2. With Output Volts selected on the Adjustments Menu screen, press the up or down arrow button to adjust the voltage to the desired setting
- 3. The control allows an adjustment of 240 VAC \pm 7% (17 VAC).
- 4. Press the BACK button to save the settings and return to the home screen.

3.4 To Enable/Disable Standby

You should normally not have occasion to disable generator set STANDBY.

- STANDBY should always be enabled (ON) except during maintenance/service.
- STANDBY will have to be re-enabled (STANDBY OFF light on) if the generator set is started or stopped manually (normally a maintenance/service function) or a fault shutdown has occurred.

⚠ CAUTION

When STANDBY is disabled the generator set will NOT automatically start to supply power if utility power is interrupted.

To enable or disable generator set standby:

- 1. Press the STANDBY ON/OFF button on the operator panel, which takes you to the Standby ON/OFF screen.
- 2. Press the up or down arrow button to select ON or OFF.
- 3. **To enable STANDBY** select ON and press the BACK button. The STANDBY OFF lamp will go out and the display will state: "Standby ready enabled by user."
- 4. **To disable STANDBY** select OFF and press the BACK button. The STANDBY OFF lamp will come on and the display will state: "Standby ready disabled by user."




FIGURE 10. ENABLE/DISABLE STANDBY SCREEN

3.5 To Manually Start/Stop Generator Set

Normally only the maintenance/service technician has occasion to manually start and stop the generator set.

Starting the generator set will result in the generator powering the house loads.

⚠ CAUTION

Manually starting or stopping the generator set disables generator set STANDBY. The generator set will not automatically start to supply power if utility power is interrupted.

Manually start and stop the generator set once every 3 months to test that these functions are working properly.

To manually start or stop the generator set:

- 1. Press the START STOP button on the operator panel, which takes you to the Genset START/STOP screen.
 - The screen will display "Genset Stopped" or "Genset Running," as appropriate.
- 2. Press START to manually start the generator set and connect it to supply power to the house. The STANDBY OFF lamp will come on and the display will state: "Genset started manually (Standby Ready Disabled)."
- 3. Press STOP to manually stop the generator set and disconnect it. The STANDBY OFF lamp will come on and the display will state: "Genset stopped manually (Standby Ready Disabled)."

NOTICE

To start the generator set without connecting loads pick Exercise Now on the Exerciser Clock screen.




FIGURE 11. GENSET START/STOP SCREEN

3.6 Fault, Maintenance and New Event Screens

Various warning and event screens may appear on the operator panel during Normal or Emergency Operation.

3.6.1 Fault Screen

If a generator set shutdown fault occurs, a FAULT warning appears with the following information:

- Brief description of the warning or fault
- The two-digit Fault Code Number
- The time of occurrence of the fault

Press the BACK button to reset the fault and return to the home screen.

See the Fault Log section of this manual to review the log of the last 5 faults.




FIGURE 12. TYPICAL FAULT SCREEN

3.6.2 Maintenance Due Screen

A Maintenance Due screen appears when a scheduled maintenance operation is due.

- The warning does not time out.
- · Perform the maintenance.

Press the BACK button to return to the home screen.




FIGURE 13. TYPICAL MAINTENANCE DUE SCREEN

3.6.3 New Event Screen

A New Event screen appears whenever system status changes, such as when there is an interruption of utility power. The screen provides a brief description of the event along with the time and date of the event.

The message does not time out, unless superseded by a new event.

• Press the BACK button to return to the home screen.




FIGURE 14. TYPICAL NEW EVENT SCREEN

3.7 Exercise Settings

To set the generator set exercise schedule:

- 1. Press the EXCER button on the home screen.
- 2. Press the NEXT button on the Exerciser Clock screen to select the field to change.
- 3. Press the up or down arrow button to increase or decrease the frequency of exercise and the day of the week and time of day for exercise.

Frequency selections are:

Weekly

Bimonthly

Monthly

Never

- 4. Press the BACK button to save the settings and return to the home screen.
- 5. If you want to exercise the generator set now, select Exercise Now, and press either the up or down arrow.

NOTICE

Scheduled or prompted exercise does not transfer the house loads to the generator set.




FIGURE 15. EXERCISE CLOCK SCREEN

3.8 Time Setup

To set up the generator set clock for the current date and time:

- 1. Press the CLOCK button on the home screen.
- 2. Press the NEXT button on the Time Setup screen to select the field to change.
- 3. Press the up or down arrow button to increase or decrease or change the date or time.
- 4. Press the BACK button to save the settings and return to the home screen.




FIGURE 16. TIME SETUP SCREEN

3.9 Load Management

The generator set may have been set up at installation to connect and disconnect certain large loads, such as air conditioners, to manage the total load so as not to overload the generator set. This requires the installation of relays to the load management signals which allow for the disconnection of loads. Load management can be set to operate in **automatic** or **manual** mode.

Whether in automatic or manual mode, there is a delayed start. Load 1 is enabled three minutes after the generator set is connected to the house loads, and Load 2 is enabled six minutes after the generator set is connected to the house loads.

3.9.1 Automatic Load Management

When set to automatic mode, the user takes no action and can only view which loads are connected. Three minutes after the generator starts, the load that is connected to genset load L1 is connected. After a delay of three more minutes, the load that is connected to genset load L2 is connected. If the connection of loads L1 and L2 exceeds 95% of the generator's load capacity, they are disconnected by the generator. Following another three minute delay, the control reconnects both loads following the same connection sequence used in the first attempt (three minutes apart). If generator load capacity is exceeded again, both loads are disconnected, and no further reconnection is tried.

To select automatic load management and view whether the selected loads are connected while the generator set is running:

- 1. Press the LOAD button on the home screen.
- 2. Press the up or down arrow button to select Automatic.
- 3. Note which loads are connected or disconnected.
- 4. Press the BACK button to return to the home screen.

3.9.2 Manual Load Management

⚠ CAUTION

To reduce unnecessary loss of service, it is highly recommended that manual load management be undertaken only by an authorized Cummins Power Generation dealer.

When set to manual mode, the user is able to view, connect, and disconnect loads. If the connection of loads L1 and L2 exceeds generator capacity, the AC circuit breaker trips.

To select manual load management when the generator is running:

- 1. Press the LOAD button on the home screen.
- 2. Press the up or down arrow button to select Manual.
- 3. Note which loads are connected or disconnected.
- 4. Press the double-down arrow button to go the load connect/disconnect screen.
- 5. Connect or disconnect Load 1 or Load 2 as necessary by pressing either button under Load 1 or Load 2.
- 6. Press the BACK button to save the setting and return to the home screen.




FIGURE 17. LOAD MANAGEMENT SCREEN

3.10 Genset Status

To check generator set output voltage and frequency and the total numbers of hours run:

- 1. Press the MENU button on the home screen.
- 2. Press the up or down arrow button on the menu screen to select Genset Status.
- 3. Press the ENTER button on the menu screen and note the values displayed on the Genset Status screen.
- 4. Press the BACK button to return to the home screen.




FIGURE 18. GENERATOR SET STATUS SCREEN

3.11 Display Setup and Software Info

3.11.1 Brightness and Contrast

To change the Brightness and Contrast of the display screen:

- 1. Press the MENU button on the home screen.
- 2. Press the up or down arrow button on the menu screen to select Display Setup.
- 3. Press the ENTER button on the menu screen.
- 4. Press the NEXT button to select Brightness or Contrast.
- 5. Press the increase or decrease arrow button to increase or decrease brightness.
- 6. Change Contrast the same way as Brightness.
- 7. Press the BACK button to save the settings and return to the home screen.




FIGURE 19. DISPLAY SETUP AND SOFTWARE INFO SCREENS

3.11.2 Software Info

To check on the generator set and display software:

- 1. Press the MENU button on the home screen.
- 2. Press the up or down arrow button on the menu screen to select Display Setup.
- 3. Press the ENTER button on the menu screen.
- 4. Press the INFO button on the Display Setup screen and note the values displayed on the Software Info screen.
- 5. Press the BACK button to return to the home screen.

3.12 Event Log

3.12.1 To Check Log of Last 20 Events

- 1. Press the MENU button on the home screen.
- 2. Press the up or down arrow button on the menu screen to select Event Log.
- 3. Press the ENTER button on the menu screen.
- 4. Scroll through the event log with the up and down double-arrow buttons. Each screen provides a brief description of the event along with the time and date of the event.
- 5. Press the BACK button to return to the home screen.




FIGURE 20. EVENT LOG SCREEN

3.12.2 List of Recordable Events

- "Genset started manually (Standby Ready Disabled)"
- "Genset stopped manually (Standby Ready Disabled)"
- "Genset exercise started"
- "Genset exercise completed"
- "Genset started due to loss of utility"

- "Genset stopped with return of utility"
- "Switch on genset moved to remote position"
- "Switch on genset moved to run position"
- · "Switch on genset moved to off position"
- "Standby ready disabled by user"
- "Standby ready enabled by user"
- "Utility lost not in Standby Ready"
- "Utility returned not in Standby Ready"
- "Maintenance reminder Change oil and check valve lash"
- "Maintenance reminder Change oil & filter, air filter, adjust valve lash, clean and check battery & engine cooling fins"
- "Genset fault (Fault description appended)"
- · "Genset warning Transfer Switch Signal Failure"
- · "Genset warning Transfer Switch Failed to Transfer to Utility"
- "Genset warning Low Battery or Battery Charger Failure"

3.13 Fault Log

To check the log of the last 5 faults:

- 1. Press the MENU button on the home screen.
- 2. Press the up or down arrow button on the menu screen to select Fault Log.
- 3. Press the ENTER button on the menu screen.
- 4. Scroll through the fault log with the up and down double-arrow buttons. Each screen provides a brief description of the fault, the fault code number and the time and date of the fault.
- 5. Press the BACK button to return to the home screen

NOTICE

If there are no faults recorded, the "No Stored Faults" screen will appear.




FIGURE 21. FAULT LOG SCREEN

This page is intentionally blank.

4 Maintenance

4.1 Periodic Maintenance Schedule

Periodic maintenance is essential for top generator set performance. Use the Maintenance Frequency table as a guide for normal periodic maintenance.

- In hot and dusty environments some maintenance procedures should be performed more frequently, as indicated by the footnotes in the table.
- Maintenance, replacement or repair of emission control devices and systems may be performed by any engine repair establishment or individual.
 - Warranty work MUST be completed by an authorized Cummins Power Generation dealer.

⚠ WARNING

Accidental or remote starting of the generator set can cause severe personal injury or death. Before working on the generator set, move the switch (S2) to the Stop position, disconnect the remote harness (P7) to disable the ATS mounted charger and remove the negative (–) battery cable from the battery to prevent starting.

TABLE 9. MAINTENANCE FREQUENCY

Maintenance Task	Maintenance Frequency						
	Daily	After First 20 hours	Yearly or Every 150 Hours	Every 300 Hours	Every 450 Hours		
Check Engine Oil Level	X	Х					
Change Engine Oil and Oil Filter		X	X ^{1,2,3}				
Adjust Engine Valve Clearance (Lash)		X ⁵	X ⁵				
Replace Engine Air Filter			Х				
Clean and Check Starting Battery				Х			
Replace Spark Plugs and Wires					X ⁴		
Clean Engine Cooling Fins					X ⁴		

- 1. Perform more often when operating in dusty conditions.
- 2. Perform first time at 20 hours.
- 3. Perform more often when operating in hot weather.
- 4. Perform sooner if engine performance deteriorates.
- Must be performed by a qualified mechanic (authorized Cummins dealer).

4. Maintenance 11-2015

4.2 Cleaning the Housing Top

The top surface of the generator set housing can be damaged by pressure washing or solvents and other cleaning agents. Only use soap and water or an "all citrus degreaser" to clean the top.

4.3 Exercising the Generator Set

Exercising the generator set drives off moisture, re-lubricates the engine and removes oxides from electrical contacts. The result is better starting, more reliable operation and longer engine life.

The generator set exerciser is capable of automatically starting the generator set and letting it run for 20 minutes, once every 28 days, or more often, if desired.

Refer to the **Exercise Settings** section of this manual for more information on setting up the exerciser.

4.4 Engine Oil Maintenance

4.4.1 Recommended Engine Oil

Check the oil level prior to starting the generator set to verify that the oil level is between the FULL and ADD marks.

- The generator set is shipped with engine oil
 - Any 40W synthetic oil can be used for normal operating temperatures.
 - For cold weather operation (below -10 °F), Mobil1 0W-40 synthetic engine oil is recommended.

4.4.2 Checking Engine Oil Level

⚠ WARNING

State and federal agencies have determined that contact with used engine oil can cause cancer or reproductive toxicity. Avoid skin contact and breathing of vapors. Use rubber gloves and wash exposed skin. Accidental or remote starting of the generator set can cause severe personal injury or death. Disconnect the negative (–) battery cable and place the control switch in its OFF position before starting work.

- 1. Pull out the dip stick and wipe it clean.
- 2. Reinsert the dip stick.
- 3. Remove the dipstick one final time, and check the oil level.

NOTICE

The engine oil level indicated on the dipstick should be between the FULL and ADD marks.

4. Reinsert the dipstick.

11-2015 4. Maintenance

If the engine oil level check shows excessive or insufficient levels of oil (oil level line above the FULL mark or below the ADD mark), oil must be drained or added. Refer to the following sections Drain Oil or Add Oil as needed) for instructions and guidelines for draining and adding oil.

4.4.3 Add or Drain Oil

⚠ CAUTION

Too much oil can cause high oil consumption. Too little oil can cause severe engine damage. Keep the oil level between the FULL and ADD marks on the dipstick.

4.4.3.1 Drain Oil

If the oil level is found to be excessive (see **Checking Engine Oil Level**), oil must be drained from the engine.

- 1. Attach one end of the drain hose (shipped loose with the genset) to the oil drain valve
- Place the other end of the drain hose into an appropriate container.Refer to local/state regulations to determine the appropriate container for used oil.
- 3. Open the oil drain valve to release oil from the engine into the appropriate container.
- 4. Re-check the engine oil level (Checking Engine Oil Level).

Based on the results, add or drain oil.

- 5. When a sufficient amount of oil has been drained from the system:
 - a. Close the oil drain valve
 - Remove the drain hose
 - c. Wipe the oil drain valve clean
 - d. Dispose of the used oil in accordance with local/state regulations.

4.4.3.2 Add Oil

If the oil level is found to be insufficient (see Checking Engine Oil Level), oil must be added.

- 1. Add the appropriate amount of oil, based on the engine oil level check performed beforehand.
- Re-check the engine oil level (see <u>Checking Engine Oil Level</u>).
 Based on the results, add or drain oil.
- 3. Clean up and dispose of any oil in accordance with local/state regulations.

4.4.4 Changing Engine Oil and the Oil Filter

Refer to the <u>Periodic Maintenance Schedule</u> for scheduled engine oil changes and to the control panel for the oil filter part number. Change oil more often in hot and dusty environments.

1. Run the generator set until warm, shut down and place pan under the end of the oil drain hose attached to the drain valve.

4. Maintenance 11-2015

2. Make sure the oil drain hose is connected to the oil drain valve and open the drain valve. Reclose the valve when oil stops draining.

- 3. Spin off the oil filter canister and clean the filter mounting surface on the engine block. Remove the old gasket if it remains.
- 4. Make sure the gasket is in place on the new filter and apply a thin film of clean oil to the gasket. Spin the new filter on until the gasket just touches the block. Turn it an additional 1/2 to 3/4 turn. Do not overtighten.
- 5. Refill with 1.7 quarts (1.6 liters) of oil.

A CAUTION

Too much oil can cause high oil consumption. Too little oil can cause severe engine damage. Keep the oil level between the Full and Add marks.

- 6. Start and run for 30 seconds.
- 7. Shut the engine off and wait 30 seconds.
- 8. Add more oil slowly, to bring the oil level to the FULL mark on the dipstick.
- 9. Dispose of the used oil and oil filter according to local environmental regulations.

4.5 Replacing the Air Filter Element

WARNING

Before working on the generator set, move the Switch (S2) to the Stop Position, disconnect the remote harness (P7) to disable the ATS mounted charger, and remove the negative (–) battery cable from the battery to prevent starting.

Refer to the <u>Periodic Maintenance Schedule</u> for scheduled air filter replacements. Replace it more often in dusty environments.

To change the filter element:

- 1. Remove the outer and inner cover and reassemble with a new air filter element.
- 2. Make sure the outer cover is seated before tightening its wingnut.

11-2015 4. Maintenance




FIGURE 22. MAINTENANCE POINTS

4.6 Battery Maintenance

WARNING

Arcing at battery terminals or in light switches or other equipment, and flames or sparks, can ignite battery gas causing severe personal injury—Ventilate battery area before working on or near battery—Wear safety glasses—Do not smoke—Switch work light ON or OFF away from battery—Stop the generator set—Disconnect the negative (–) battery cable first and reconnect it last.

⚠ WARNING

Before working on the generator set, move the Switch (S2) to the Stop Position, disconnect the remote harness (P7) to disable the ATS mounted charger, and remove the negative (–) battery cable from the battery to prevent starting.

Refer to the <u>Periodic Maintenance Schedule</u> for scheduled battery maintenance, and follow the battery manufacturer's instructions. Have the battery charger in the transfer switch replaced if the battery keeps running down.

Always:

- 1. Keep the battery case and terminals clean and dry and the terminals tight.
- 2. Remove battery cables with a battery terminal puller. Torque threaded stud battery terminals as recommended by the battery manufacturer.
- 3. Make sure which terminal is positive (+) and which is negative (-) before making battery connections, always removing the negative (-) cable first and reconnecting it last to reduce arcing.

4. Maintenance 11-2015

NOTICE

If the battery needs to be replaced, be sure that the replacement battery specs match those found in the Specifications Table in this manual.

4.7 Spark Plugs

⚠ WARNING

Before working on the generator set, move the Switch (S2) to the Stop Position, disconnect the remote harness (P7) to disable the ATS mounted charger, and remove the negative (–) battery cable from the battery to prevent starting.

Set the genset control to the Off position before checking the spark plugs.

Refer to the **Periodic Maintenance Schedule** for scheduled spark plug replacement.

The genset has two spark plugs: one on each side of the engine. The spark plugs must be in good condition for proper engine starting and performance. A spark plug that fouls frequently or has heavy soot deposits indicates the need for engine service.

To prevent crossthreading a spark plug, always thread it in by hand until it seats. Torque the spark plug to 10 lb-ft (13.5 N-m).

Return the genset control to Auto when finished performing maintenance.

4.8 Maintenance Record

Record all periodic and unscheduled maintenance and service. See the Periodic Maintenance Schedule

Bad link:

/opt/dzd/dzd_prog/prog_docato/docato_4.9.1/docato/work/temp/dzd_temp/topleaf/eee1ce17-e263-4e2b-8cbf-1555beb061a5/en-

us/.new_components/generator_set/periodicmaintenanceschedule_stdby.xmlfor a list of scheduled maintenance frequency.

DATE	HOUR METER READING	MAINTENANCE OR SERVICE PERFORMED			

11-2015 4. Maintenance

		T					
DATE	HOUR METER READING	MAINTENANCE OR SERVICE PERFORMED					

Record the name, address, and phone number of your authorized Cummins Power Generation service center.

4. Maintenance 11-2015

This page is intentionally blank.

5 Troubleshooting

By regularly performing the following periodic maintenance and guidelines, you greatly reduce the chances of a genset shutdown.

- Maintain an appropriate oil level
- · Keep battery connections clean and tight
- · Do not overload the generator set
- · Keep the air inlet and outlet openings clear

5.1 Troubleshooting With the In-Home Operator Panel

If a fault shutdown occurs the ACTION REQUIRED lamp on the in-home Operator Panel will come on and the LCD screen will display the a description of the Fault, the Fault Number, and the hour in total generator set running time when the Fault occurred.

The shutdown codes are listed below in numerical order along with step-by-step corrective actions.

5.2 Fault Code Blinking

At fault shutdown, the status indicator light will repeatedly blink sets of 1, 2, 3 or 4 blinks.

- One blink indicates shutdown due to high engine temperature.
- Two blinks indicate shutdown due to a loss of engine oil pressure.
- Three blinks indicate a service fault. Press Stop once to cause the two-digit, second-level shutdown code to blink. (Pressing Stop again will stop the blinking.) The two-digit code consists of 1, 2, 3, 4 or 5 blinks, a brief pause, and then 1 to 9 blinks. The first set of blinks represents the tens digit and the second set of blinks the units digit of the shutdown code number.
- Four blinks indicate that cranking time exceeded 35 seconds.
- Fault Code Nos. 1, 2, 3, and 4 are first level faults. Pay close attention to the pause sequence to avoid interpreting first level faults as second-level Fault Codes Nos. 11, 22, 33, or 44.
- To avoid the possibility of anyone misinterpreting Code Nos. 3 and 4 as Code Nos. 33 and 44, the latter have not been assigned faults.

5.3 Restoring Fault Code Blinking

The fault code stops blinking after five minutes. Press **Stop** three times within three seconds to restore fault code blinking.

NOTICE

The last fault logged will blink even though the condition that caused the shutdown may have been corrected.

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

5.4 Troubleshooting with the Flashing Indicator Light

The status indicator light on the Control Switch inside the generator set flashes the diagnostic fault code when a fault shutdown occurs. For a single-digit fault code (2 or 4), the light will flash 2 or 4 times and after a short pause will repeat.

For a two-digit fault code the light will flash the tens digit, pause and flash the units digit and repeat after a longer pause. Fault 36 would be flashed as follows:

flash-flash-flash-mause —flash-flash-flash-flash-flash-flash-long pause —repeat

NOTICE

For fault history, go to the in-home Operator Panel.

5.4.1 Starting Battery Runs Down

Possible Cause: Marginal battery connections, battery, charging system, excessive cranking Corrective Actions:

- 1. Clean and tighten positive (+) and negative (-) battery cable connections at the battery.
- 2. Recharge or replace battery. Refer to the battery manufacturer's recommendations.
- 3. Have battery charger serviced by an authorized Cummins Power Generation dealer.

5.4.2 No Response - Status Indicator Light Dead

Possible Cause: Low/No battery voltage, poor battery connection, faulty battery, open harness connection, faulty start/stop switch, faulty LED

Corrective Actions:

- Try generator set Start Switch if the remote display Start Switch does not respond, and vice versa
- 2. Clean and tighten positive (+) and negative (-) battery cable connections at the battery.
- 3. Recharge or replace battery. Refer to the battery manufacturer's recommendations.

5.4.3 Starter Engages - Disengages

Possible Cause: Cranking voltage dips below 6 VDC-Battery connections, battery, charging system, start/stop switches

Corrective Actions:

- 1. Clean and tighten positive (+) and negative (-) battery cable connections at the battery.
- 2. Recharge or replace battery. Refer to the battery manufacturer's recommendations.
- 3. Have the battery charger serviced by an authorized Cummins Power Generation dealer.

11-2015 5. Troubleshooting

5.4.4 No AC Power - Generator Set Running, Status LED On Steady or Flashing Rapidly

Possible Cause: Circuit breakers tripped due to short circuit or overloading.

Corrective Actions:

- 1. Reduce number of loads.
- 2. Reset or turn on generator set circuit breaker.
- 3. Reset or turn on circuit breaker in the distribution panel.
- 4. Have the circuits from the generator set and the distribution panel verified by an authorized electrician.

5.4.5 Generator Set Cranks But Does Not Start - No Fault Code

Possible Cause: Faulty or incorrect spark plugs.

Corrective Actions:

- 1. Check and record last fault code.
- 2. Crank generator set and troubleshoot fault code and reference last fault code recorded above if necessary.

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

5.4.6 Genset Warning - Transfer Switch Failed to Transfer to Utility - No Fault Code

Possible Cause: Transfer switch is faulty, or wire is disconnected or broken

Corrective Actions:

1. Have the utility switch-position wire, wire connections, and transfer switch checked by an authorized electrician.

5.4.7 Low Oil Pressure Fault - Fault Code 2

Possible Cause: Oil Level too low/high, faulty switch, faulty oil pressure relief valve, faulty oil pump

Corrective Actions:

1. Check oil level: add or drain oil as necessary.

5.4.8 Overcrank - Fault Code 4

Possible Cause: Faulty switch, faulty external start command, fuel supply, air fuel mixture, exhaust system, wire connections, starter, ignition system

Corrective Actions:

1. Open any closed fuel valves.

- 2. Secure spark plug leads to spark plugs.
- 3. Check and service air filter as necessary.
- 4. Replace spark plugs.

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

5.4.9 Overvoltage - Fault Code 12

Possible Causes: Generator set loads, wire connections, windings

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.10 Undervoltage - Fault Code 13

Possible Causes: Generator set loads, wire connections, windings

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.11 Overfrequency - Fault Code 14

Possible Causes: Generator set loads, engine governor function, fuel supply, air fuel mixture, exhaust system, choke, demand regulator, carburetor, generator windings, wire connections

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.12 Underfrequency - Fault Code 15

Possible causes: Generator set loads, engine governor function, fuel supply, air fuel mixture, exhaust system, choke, demand regulator, carburetor, generator windings, ignition, wire connections

Corrective Actions:

- 1. Reduce the number of connected loads especially loads that require higher starting current such as air conditioners.
- 2. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.13 Governor Actuator shutdown - Fault Code 19

Possible causes: Wire connections, governor actuator

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

11-2015 5. Troubleshooting

5.4.14 Governor Actuator Overload - Fault Code 22

Possible causes: Generator set loads, wire connections, fuel supply, air fuel mixture, exhaust system, governor actuator, ignition system

Corrective Actions:

- 1. Reduce the number of connected loads especially loads that require higher starting current such as air conditioners.
- 2. Check and service air filter as necessary.
- 3. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.15 Voltage Sense Lost - Fault Code 27

Possible Causes: Generator set loads, generator windings, ignition, wire connections Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

5.4.16 High Battery Voltage - Fault Code 29

Possible Causes: Incorrect battery configuration, wire damage, faulty charger, control Corrective Actions:

1. Have battery charger serviced by an authorized Cummins Power Generation dealer.

5.4.17 Low Cranking Speed Sense - Fault Code 32

Possible Causes: Starter, engine components, air intake system, exhaust system, generator windings, wire connections, battery, battery connections, oil viscosity

Corrective Actions:

- 1. Clean and tighten positive (+) and negative (-) battery cable connections at the battery.
- 2. Recharge or replace battery. Refer to the battery manufacturer's recommendations.
- 3. Verify engine oil viscosity is correct for the ambient temperature. If not, refill and replace engine oil with correct viscosity.
- 4. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.18 Control Card Failure - Fault Code 35

Possible Causes: Faulty program

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.19 Generator Set Stopped Without Fault Condition - Fault Code 36

Possible Causes: Fuel supply, air fuel mixture, exhaust system, choke demand regulator, carburetor, generator windings, ignition, wire connections

Diagnosis & Repair:

- Check the fuel source.
- 2. Open any closed fuel valves.
- 3. Secure spark plug leads to spark plugs.
- 4. Check and service air filter as necessary.
- 5. Replace spark plugs.
- 6. Check for mechanical damage.

5.4.20 Invalid Set Configuration - Fault Code 37

Possible Causes: Generator set configuration, control

Diagnosis & Repair:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.21 Processor Fault - Fault Code 43

Possible Causes: Faulty program

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.22 Speed Sense Fault - Fault Code 45

Possible Causes: Loads, generator windings, wire connections

Corrective Actions:

1. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.23 Generator Set Overload - Fault Code 46

Possible causes: Loads, wire connections, windings

Corrective Actions:

- 1. Reduce the number of connected loads especially loads that require higher starting current such as air conditioners.
- 2. Check and service air filter as necessary.
- 3. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.24 Alternator Over Temp - Fault Code 76

Possible Causes: Wire connections, faulty temperature sensor, faulty DC fan, blocked intake or exhaust openings.

11-2015 5. Troubleshooting

Corrective Actions:

1. Verify the generator set enclosure for clear intake and exhaust openings.

2. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.25 Low Fuel Pressure - Fault Code 78

Possible Causes: Wire connections, fuel system, fuel pressure switch

Corrective Actions:

- 1. Open any closed fuel valves.
- 2. Have unit serviced by an authorized Cummins Power Generation dealer.

5.4.26 Failure To Transfer To Generator Set - Fault Code 79

Possible Causes: Wire connections, faulty positional switch, faulty transfer switch component(s).

Diagnosis & Solution:

- 1. Verify that the main AC circuit breaker on the generator set is to "On".
- 2. Have unit serviced by an authorized Cummins Power Generation dealer.

5.5 Communication Troubleshooting

5.5.1 In-Home Network Access to Generator Set Troubleshooting

♠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

Possible Causes: Bad connections or bad communications

Corrective Actions:

- 1. Check connections.
 - a. Verify that the Ethernet cable is plugged into the generator set control and the router.
 - b. Verify that the computer is connected to the same router as the generator set via an Ethernet cable.
 - c. Verify that the wireless card on the computer is turned off.
 - d. Check to see if both ends of the Ethernet cable are assembled and crimped as described in the installation instructions. If not, reassemble and crimp as described in the installation instructions.
 - e. Verify that the Ethernet cable connections between the generator set and the router are solid and correct.
 - f. Proceed to "Check communications."

2. Check communications.

- a. Check to see if you can access a standard web page with the computer connected to the same router as the generator set. If not, contact your router manufacturer for troubleshooting information.
- b. Check to see if the green and orange lights are illuminated at the Ethernet connection port on the generator set control board. If not, disconnect the Ethernet cable from the generator control board and connect it to the computer. Check to see if you can access a standard web page with the computer connected to the generator side of the Ethernet cable.
 - a. If you can access a standard web page, call Cummins Support at 1-800-888-6626 and select option 1.
 - b. If you cannot access a standard web page, go to "Check connections" above.
- c. Check to see if you can access the generator set via the in-home network. If not, call Cummins Support at 1-800-888-6626 and select option 1.




FIGURE 23. NETWORK CONNECTIONS (CONTROL BOARD AND ETHERNET CONNECTION)

5.5.2 Remote Internet Access to Generator Set Troubleshooting

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

Possible Causes: An improper setup, no high-speed internet connection, the public IP address is not active or properly set up, an incorrect IP address is entered, the computer is connect to the same router or network and the generator set, or the internet connection is bad,

Corrective Actions:

1. Check to see if you are able to access the generator set with your in-home computer.

11-2015 5. Troubleshooting

If not, refer to the In-Home Network Access Troubleshootingprocedures.

- 2. Verify that you are using a high-speed internet connection.
- 3. Verify that the public IP Address is active and set up properly with the ISP (Internet Service Provider). If necessary, contact the ISP to verify your setup.*
- 4. Verify that the correct public IP Address is entered into the web browser of the computer (i.e. xxx.xxx.xxx).
- 5. Verify that the computer is not connected to the same router or network as the generator set
 - The computer used for internet access must be connect to a different internet connection than the generator set.
- 6. Check to see if you can access a standard web page from a computer.
 - If not, contact the ISP to troubleshoot the internet connection.
- 7. Verify all settings, as described in the Network Setup Guide.
- 8. If the previous steps do not correct the problem, contact a computer network specialist to diagnose.
 - * To verify your IP Address, access "whatismyipaddress.com" from the browser of a computer connected to the internet and on the same network as the generator set. This web page displays your current IP Address which should match the IP Address assigned to you by your ISP.

5.5.3 Email Alert Troubleshooting

⚠ WARNING

Some Generator Set service procedures present hazards that can result in severe personal injury or death. Only trained and experienced service personnel with knowledge of fuels, electricity, and machinery hazards should perform Generator Set service.

Possible Causes: An improper setup, the alert level is not set to "all events," emails cannot be received, the outgoing email address is not included in your contact list, the email account is not capable of using port 25 with plain SMTP for the outgoing SMTP server setup, the domain name is not included in the user name filed of the Network Setup screen, or the DNS #1 and #2 values are incorrect on the Network Setup screen.

Corrective Actions:

- Check to see if you are able to access the generator set with your in-home computer. If not, refer to In-Home Network Access Troubleshooting.
- 2. Verify that the alert level is set to All Events.
 - a. To verify that your generator set can send emails, select Disable Standby and wait several minutes to verify that you did receive an email.
 - b. Select Enable Standby and wait a few more minutes to verify that you did receive a second email.
- Send an email to the destination email address and check to see if you received this email.
 If not, contact your email service provider or your ISP (Internet service provider) to diagnose.

- 4. Check to see if the destination email accounts have spam filtering.
 - a. If spam filtering is present, add the outgoing email address to your contact list.
 - b. If spam filtering is not present, proceed to step 6.
- 5. Check to see if you are using an email account capable of using port 25 with plain authentication SMTP server setup.
 - If necessary, obtain an email account capable of using port 25 with plain authentication SMTP and enter detail into the network setup screen.
- 6. Verify that the domain name is included in the user name field of the Network Setup screen (i.e. username@domainname).**
- 7. Verify with your ISP that the Static DNS (Domain Name Server) #1 and #2 are correct.
- 8. If the previous steps do not correct the problem, contact a computer network specialist to diagnose.
- ** "No authentication" is possible by leaving the username and password fields blank.

IMPORTANT NOTE: Changes are not saved unless you navigate through all three Network Setup screens and click on "Done". The message "Settings Saved Successfully" is then displayed.




FIGURE 24. NETWORK SETUP - PAGE 1

11-2015 5. Troubleshooting




FIGURE 25. GENERATOR SET HOME PAGE




FIGURE 26. NETWORK SETUP - PAGE 2




FIGURE 27. NETWORK SETUP - PAGE 3

6 Optional Internet/Email Interface Descriptions

6.1 Introduction

This feature allows for in-home or remote access to your generator set through a web page.

NOTICE

An Internet browser (i.e., Internet Explorer) is required for this option.

On this web page, you can start or stop the generator set, adjust the exerciser day and time, determine if utility power is available and view the last 20 events/faults on the generator set.

This feature is useful for homeowners who travel or have a second home and want to be able to remotely interface with their generator set. This feature can also help to reduce troubleshooting time and service calls when the service technician has access to the same web page.

Use of the Ethernet is not required if you do not use web access. To set up your generator set for web access, complete installation instructions are included in the Network Setup Guide instruction sheet, included with your generator set literature package.

The Internet/Email Interface can make the same fault, maintenance and event notices available to you and to your generator set service contract agency with appropriate Internet Service and email account.

NOTICE

Technical support for setup and troubleshooting of the hardware used for in-home network access to the generator set is available through the selling Cummins Power Generation dealer/distributor.

The owner may be required to contact their ISP and/or email provider for technical support of the email notification feature setup and troubleshooting.

Due to the variations in network equipment, network configurations and ISPs, the owner is responsible for acquiring the needed support/service from a qualified network specialist to properly and securely set up the owner's network for remote monitoring of the generator set. Cummins Power Generation does not provide technical support for setup and troubleshooting of the owner's network and email service.

6.2 Screen Descriptions




FIGURE 28. HOME PAGE

6.2.1 Setting Time and Date

Select the Genset Time/Date Tab on the Home Screen to set the time and date for the generator set control.




FIGURE 29. SET GENSET TIME AND DATE

6.2.2 Set Exercise Schedule

Select the Exercise Schedule Tab on the Home Screen to set the generator set exercise schedule.

NOTICE

The generator set will exercise on the first scheduled day for which it is programmed. After that it exercises on that day at the scheduled interval. For example, if the generator set is scheduled on a Wednesday for Saturdays with a monthly interval, the generator set starts on the next available Saturday. After that it exercises on Saturdays one month apart.



FIGURE 30. SET EXERCISE SCHEDULE

6.2.3 Load Control (Management)

Select the Load Control Tab on the Home Screen to enable Automatic or Manual Load Control. In Automatic mode, the user can only view which loads are connected. In Manual mode, the user can view loads and also connect or disconnect them. See **Load Management** for details.




FIGURE 31. GENSET LOAD MANAGEMENT

6.2.4 Event Log

Select the Event Log Tab on the Home Screen to review the last 20 events. See the Event Log screen capture below for a list of all of the recordable events.




FIGURE 32. EVENT LOG

6.2.5 Fault Log

Insert the body content of the topic

Select the Fault Log Tab on the Home Screen to review the last 5 faults.




FIGURE 33. FAULT LOG

6.2.6 Network Setup Screen Descriptions

An owner-custom password can be defined in the Network Setup screen shown below. The user will be prompted to enter the User Name and Password to access this screen, this screen also allows the user to change their password. The default User Name and Password are listed below.

User Name: admin Password: cummins

The Network Setup Parameters screen allows dynamic addresses to be changed to static addresses. This screen allows the user to configure the static address for the in-home network. See the Network Setup Parameters screen shown below.



FIGURE 34. NETWORK SETUP SCREEN




FIGURE 35. NETWORK SETUP PARAMETERS

6.2.7 Email Setup Screen Descriptions

The user must determine what events will trigger an email notification of the event:

- Never
- All Events
- Maintenance and Attention Required or Attention Required Only

This screen is also used to set up ISP configuration.

The user may enter up to three email addresses for receiving notifications of the home-standby generator set status. See the Email Addresses figure below.




FIGURE 36. EMAIL SETUP PARAMETERS




FIGURE 37. EMAIL ADDRESSES

6.2.8 Saving Changes

After the email addresses are added and Done is selected, this screen will appear, verifying that all changes have been saved.




FIGURE 38. SAVE SCREEN

6.3 Ethernet Connections (Optional)

Wiring connections to the Ethernet RJ-45 plug are shown in the Ethernet RJ-45 Connector Wiring illustration. Utilize an appropriate Ethernet stripping and crimping tool for these connections.




FIGURE 39. ETHERNET CONNECTOR




FIGURE 40. ETHERNET RJ-45 CONNECTOR WIRING




FIGURE 41. NETWORK CONNECTIONS



www.cumminspower.com

Cummins, the "C" logo, and "Our energy working for you." are trademarks of Cummins Inc.

Copyright © 2014 Cummins Power Generation, Inc. All rights reserved.