



NEMA
L5-30R

- Heavy-duty marine grade construction
- Designed for use with 16/3 through 10/3 cable
- Dust seal keeps contaminants out
- Powerful strain relief secures cord with stainless steel screws

WIRING INSTRUCTIONS

⚠ WARNING To prevent electrocution, make sure the cable is not connected to a power source before installing a device. Failure to comply with the following instructions could cause an electrical failure or fire.

1. Back out the recessed screws on the front face and separate the sections.
2. Slide the housing over the cord.
3. Strip the cable jacket 1-1/8" and strip each of the wires 5/8". Make sure the wire is clean and a bright copper color. Do not solder the ends of the wire.
4. Fully insert each wire under the clamp of the appropriate wire terminal. Make certain there is not wire insulation under any terminal clamp. Tighten the screw clamps to 20 in-lbs of torque. Do not over tighten.
5. Recouple the two sections then tighten down the recessed screws with moderate torque.
6. Tighten the cord clamp by tightening the two assembly screws to 16-20 in-lbs of torque.