

# Installation Instructions for Meter Box

## Models MB75 and MB125



### Specifications:

Model	Absolute Maximum Electrical Ratings
<b>MB75</b>	30A (7.5kW), 125/250 VAC
<b>MB125</b>	50A (12.5kW), 125/250 VAC

This electrical metering product is designed to indicate the power draw from an auxiliary power source, such as a generator, through a transfer switch or panel.

### Cautionary Notes:

1. This installation shall be made in accordance with the National Electrical Code (NFPA 70) and all applicable local codes. This product is not to be used or installed in such a manner that would expose it to voltage, current, or power levels above the listed absolute maxima. Doing so will void the product warranty and could result in hazardous operating conditions.
2. This product is intended to be used on 125/250 VAC, 60Hz power circuits. Connection to circuits of other voltage and current will result in unacceptable measurement errors.
3. Do not install the product in a location where the ambient air temperature exceeds 40C (104°F).
4. Do not use the product with the wiring compartment cover removed or missing.
5. The installer is responsible for providing the appropriate sized conductors and overcurrent protection for wiring leading to and from the product. Overcurrent protection can be any device suitable for branch circuit protection (i.e. UL 489 circuit breakers, UL 248 fuses, etc.)

Model	Minimum Conductor Size - AWG	Overcurrent Protector Rating
<b>MB75</b>	10	30 A
<b>MB125</b>	8	50 A

Do not use wire larger than AWG 8.

### Installation:

Open door and remove mechanism. To do so, remove screw at bottom of front plate. Pull the wiring compartment cover forward with a screwdriver or other tool, and pull down to remove. Loosen screw at top center of front panel, tip mechanism forward and lift out. Screw is captive and will not fall out of plate.

Mount the enclosure to the wall by means of the openings provided.

Replace the mechanism into the enclosure. To do so, set mechanism on tabs and tip backwards. Secure into cabinet by tightening captive screw at top center of front panel.

**Wiring:** Un-wrap current transformers in the wiring compartment. These transformers are already connected to the meters. Insert one of the two hot legs from the generator to the transfer switch through the opening in one of the current transformers. Insert the second hot leg from the generator through the opening in the other current transformer.

**When wiring is completed, be sure to replace the wiring compartment cover and retaining screw.**



RELIANCE CONTROLS CORPORATION / 2001 YOUNG CT.  
RACINE, WI 53404 / (800)-634-6155